

Manual No: 501089100002-EN


Manual Version: A

Jan. 2024

Translated version

Operation Manual

0608ME All/1932ME All



GB **CE** **ANSI** **SA** **EAC**

SINOBOOM



WARNING

Operating, servicing and maintaining this vehicle or equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure and avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle or equipment in a well-ventilated area and wear gloves or wash your hands frequently when servicing. For more information, go to: www.P65warnings.ca.gov.

For disposal, please comply with local regulations.

SINOBOOM



星邦智能

星邦

All of the above are registered trademarks of **Hunan Sinoboom
Intelligent Equipment Co., Ltd.**

Contact us:

Website:www.sinoboom.com.cn/www.sinoboom.com

Sales Tel:+86 400-601-5828/+86-0731-87116222

Service Tel:+86 400-608-1289/+86-0731-87116333

E-mail:info@sinoboom.com/sales@sinoboom.com

Address: No.128, East Jinzhou Avenue, Ningxiang High-tech Industrial Park, Changsha,
Hunan, China

Postal code:410600

Copyright©Hunan Sinoboom Intelligent Equipment Co., Ltd.

Hunan Sinoboom Intelligent Equipment Co., Ltd. retains the right of final interpretation of the manual.

To Users

Thank you for choosing and using the machinery of **Hunan Sinoboom Intelligent Equipment Co., Ltd.**

Use this machine only to transport tools to work locations and for performing tasks on the work platform. Only authorized personnel who have received appropriate MEWP training may operate this machine. Before using the machine, carefully read and fully understand this manual and strictly follow its relevant instructions. Different countries, regions, or governments may have equipment operating regulations that conflict with this manual. The stricter safety operating regulations should be followed. Our company will not be liable for any adverse consequences arising from the failure to operate and use the machine in accordance with this manual or the relevant regulations.

This manual provides necessary safety precautions and operation instructions for users. This manual covers the basic configuration information of one or more models. Please refer to the information applicable to your machine model. Treat this manual as an integral part of the machine and keep it with the machine at all times. This manual may not be copied, distributed, sold, or altered without written permission from Sinoboom.

Due to continuous improvement and upgrading of product design and different product models covered, some charts and textual content in the manual may be not applicable to your machine. Our company reserves the right to revise the contents of this manual due to technological improvements. Changes will be made without prior notice. Contact Sinoboom to obtain the most current version of the manual.

Please go to www.sinoboom.com.cn to download your desired Operation Manual, Maintenance Manual and Parts Manual.

If you have any questions, contact **Hunan Sinoboom Intelligent Equipment Co., Ltd.**

Manual Revision History:

[illegible]

Applicable Models

The manual applies to the following models and serial numbers:

Model	Metric Trade Name	Imperial Trade Name	Serial No.
0608ME All	0608ME All	1932ME All	0108900100 to present

Note:

- Check the machine model and serial number on the machine nameplate. The location of the nameplate can be found in the ***Decals Diagram*** section of the Operation Manual.
- Product model numbers are indicated on the nameplates to distinguish products with different main technical parameters.
- Product trade names (product commercial codes) are used for marketing purposes and machine decals for the differentiation of products with different main technical parameters. Product trade names are categorized as metric and imperial trade names: metric trade names are applicable to regions/countries using the metric system or as specifically requested by customers; imperial trade names are applicable to regions/countries using the imperial system or as specifically requested by customers.

CONTENTS

1	Safety Warning Symbols and Signs	1
2	Important Safety Rules	5
2.1	General	5
2.2	Preparing for Operation	5
2.3	Operation Safety	6
2.4	Towing, Hauling and Lifting Safety	13
2.5	Maintenance Safety	14
3	Responsibilities of Relevant Parties	19
3.1	Owner's (or Lessor's) Responsibilities	19
3.2	Employer's Responsibilities	19
3.3	Trainer's Responsibilities	19
3.4	User's Responsibilities	19
4	Technical Parameters	21
4.1	Machine Specifications	21
4.2	Function Speed	23
5	Pre-operation Inspection	25
5.1	Basic Machine Components	26
5.2	Machine Positions	27
5.3	Pre-start Test	27
5.4	Functional Test	28
6	Controllers and Indicators	31
6.1	Ground Controller	31
6.2	Platform Controller (Sinoboom Control System)	33
7	Operation Instructions	35
7.1	General	35
7.2	Gradeability	35
7.3	Activating the Machine	35
7.4	Charging the Battery	36
	Description of Battery Level Indications	36
	Charger LED Description	37
7.5	Lifting and Lowering the Platform	37
7.6	Traveling	38
7.7	Extending and Retracting Platform	39
7.8	Folding and Unfolding Platform Guardrails	39
7.9	Turning Off and Stopping	41
7.10	Transport and Lifting	42
7.11	Storage	44
8	Emergency Procedures	45
8.1	Reporting Accidents	45
8.2	Emergency Operation	45
8.3	Emergency Lowering	45
8.4	Emergency Towing	46
9	Decals Diagram	49
10	Maintenance	53
10.1	Tire Assembly	53
	Checking Tires and Rims	53
	Checking Wheel Nuts	53
	Replacement Requirements	53
	Replacing Tires	54
10.2	Inspection and Preventive Maintenance Schedule	54
	Pre-delivery Inspection (PDI)	54

Pre-operation Inspection	54
Regular Inspections	54
Annual Inspection.....	54
Preventive Maintenance	55
Responsible Persons and Qualifi- cations for Performing Inspection and Maintenance	55
Inspection and Preventive Mainte- nance Schedule	55

1 SAFETY WARNING SYMBOLS AND SIGNS

The safety warning symbols used on the machine and in the manuals have the following meanings:



Safety warning symbol. This symbol is used to alert you to potential hazards. Observe all safety instructions following a symbol to avoid possible injuries.



DANGER

Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.



WARNING

Indicates an imminently hazardous situation that, if not avoided, could result in death or serious injury.

















CAUTION










Indicates an imminently hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates information directly or indirectly related to personal safety, machine damage, or property loss.

The safety signs used on the machine and in the manuals have the following meanings:

 Refer to the Maintenance Manual	 Anchor point only for 1 person	 Wind speed	 Chemical burns hazard	 Wedge the wheel
 Refer to the Operation Manual	 Add lubricant	 Crushing hazard – safety shoes required	 Wind	 Alarm sounding
 Replace with tires of the same specification	 Do not use damaged power cords	 Temperature	 Horn	 Noise level
 Press the directional-control valve	 Release the brake	 Pull out-ON Press-OFF	 Collision hazards - never release the brake on slope	 Engage the safety arm
 Only trained maintenance personnel can check the compartment	 Electrocution hazard on platform	 Electrocution hazard on the ground and platform	 Tipping hazard – avoid uneven ground	 Tipping hazard – avoid uneven ground
 Tipping hazard – never use machine in strong, gusty winds	 Tipping hazard – never use machine in strong, gusty winds	 Tipping hazard – never push or pull objects outside the platform	 Tipping hazard – never suspend objects from the platform	 Tipping hazard – never place ladders and scaffolding on the platform
				

Tipping hazard – never leave the door open  Fall hazard – never climb on platform guardrails	Collision hazard – keep head clear of overhead obstacles when raising platform  Fall hazards – never climb on scissor arms	Crushing hazard – keep hands clear from overhead obstacles when raising platform  Keep a safe distance from power lines	Collision hazard – keep the platform clear of obstacles below when lowering the platform  Battery charging plug	Crushing hazards – keep hands away from scissor arms when lowering the platform  Platform power plug
 Platform up and down movement	 Indoor use	 Outdoor use	 Emergency lowering handle position	 Maximum platform height
 Only qualified maintenance personnel may perform maintenance work	 Wear protective clothing and safety goggles	 Lateral force	 Electrocution hazard	 Battery explosion hazard
 No smoking or open flames/sparks	 No smoking or open flames/sparks	 Lifting point	 Lashing point	 Tire ground pressure
 Forklift pocket position	 Close the chassis door	 Tool or weight	 Fast/high speed	 Slow/low speed
 Platform load capacity	 Respective load capacity of main platform and platform extension			

This Page Intentionally Left Blank

2 IMPORTANT SAFETY RULES

2.1 GENERAL

This chapter briefly describes the precautions that must be followed for safe and proper operation and maintenance of this machine. To ensure safe use and proper operation of the machine, the operator must perform routine maintenance on the machine in accordance with the Operation Manual and Maintenance Manual. In addition, the machine must be regularly maintained and serviced by a qualified service technician according to the instructions provided in the Maintenance Manual.

Familiarize yourself with the local regulations concerning Mobile Elevated Work Platforms (MEWPs) and related operations. The rules for equipment operation from different countries, regions, or governments may conflict with this manual, so the stricter safety operation rules should be followed. If you have any questions about safety, training, inspection, maintenance, purposes and operation of the machine, please contact Hunan Sinoboom Intelligent Equipment Co., Ltd.

Sinoboom cannot foresee all the potential hazards related to this machine, so all parties involved should place high importance on safety issues.



WARNING

Failure to follow the operating instructions and safety rules in this manual may result in machine damage, property loss, or personal injury.

2.2 PREPARING FOR OPERATION

Operator's Training and Knowledge Requirements

Before operating this machine, read, understand, and comply with all applicable regulations and requirements of employers, local authorities, and the government related to equipment use.

Before operating this machine, you should read and fully understand this manual, undergo professional training based on this Operation Manual, and only operate this machine independently after acquiring the qualification for proficient operation. The training content should include, but not be limited to, the following topics:

- Warnings, operating instructions, and the Operation Manual on the machine.

- Pre-start test
- Factors affecting the stability of the machine
- Common hazards and how to avoid them
- Workplace Inspection
- Functions and related knowledge of all controls, including emergency controls
- Use of personal protective equipment appropriate to the work task, workplace, and environment
- Safe operation
- Transport
- How to prevent unauthorized use

Workplace Inspection

Before and during the operation of the machine, users must pay attention to the hazards and take preventive measures to avoid hazards in the work area. Without the written permission of Hunan Sinoboom Intelligent Equipment Co., Ltd., this machine shall not be used in the following areas or conditions:

- Steep slopes or caves
- Ground with protrusions, obstacles, or debris
- Insecure or slippery surfaces
- Surfaces not sufficient to support the machine (machine weight + load weight)
- Trucks, trailers, rail cars, ships, or other equipment
- Dangerous locations
- Places with overhead electric wires, cranes, or other potential obstacles
- In gusty and/or strong wind conditions, or lightning
- Unauthorized persons
- Other areas where unsafe conditions may occur

Machine Inspection

Make sure to complete all checks in strict accordance with the steps in the **Pre-operation Inspection** section of this manual before operating the machine:

- **Pre-start test**: Ensure that no components are loose/loosening, missing or altered. Components must be securely fixed, without visible damage, leakage, or excessive wear, etc., all parts must be in their original locations and operating position; make sure that all fluid levels, battery level, etc. are appropriate; ensure that maintenance work has been completed

in accordance with the requirements specified in the Maintenance Manual.

- **Decals inspection** : Ensure that no decals and nameplates are missing and/or damaged; decals must be clearly visible.
- **Functional test** : Make sure that all functions of the machine are working properly.



WARNING

It is forbidden to alter or modify the machine without the written permission of Hunan Sinoboom Intelligent Equipment Co., Ltd.

2.3 OPERATION SAFETY

General

WARNING



- This machine shall only be used to transport tools to work locations and for performing tasks on the work platform, and should not be used for other purposes.
- Operators should use personal fall protection equipment (PFPE) while operating the machine. If workplace or other rules require the use of PFPE by persons on the platform, the PFPE should be inspected and used in accordance with the PFPE manufacturer's instructions and applicable government requirements.
- The operator must devote their full attention to their work during the operation of the machine. The use of mobile phones, wireless communication devices, etc. may distract the operator and affect the safe operation of the machine, so the operator should completely stop the machine before using such devices.
- Remove all rings, watches and other accessories before operating the machine, do not wear loose clothing, and do not let long hair hang loosely.
- Individuals who have consumed alcohol or taken medication, who are overly fatigued or mentally distressed, who suffer from health conditions such as heart disease, high blood pressure, epilepsy, etc., individuals with a fear of heights or who feel unwell are prohibited from operating the machine.
- Do not operate a damaged or malfunctioning machine. In case of any failure, stop the machine immediately, label the machine appropriately, and contact the manufacturer or relevant department.
- Never disassemble, modify or retrofit the machine or its parts.
- Never disable any safety devices of the machine.
- Never place objects on the platform guardrails.

WARNING

- Never push the control switch or joystick forcefully through the neutral position directly into the opposite direction. Before pushing the switch to the next function position, move it back to the neutral position and stop, and then move it with slow and uniform force to perform the next function.
- Except in case of emergency, it is forbidden to perform operations from the ground if any person is still on the platform.
- When there are two or more people on the platform, all operation of the machine must be conducted by the operator.
- Always operate the machine in well-ventilated conditions to avoid carbon monoxide or nitrogen oxide poisoning.
- Before leaving the machine, the platform should be completely lowered and all power should be shut off.

Electrocution Hazard

⚠ WARNING





- This machine is not insulated and not equipped with electrocution protection function.
- Do not use this machine during thunderstorms or heavy rain. Should you encounter thunderstorms or heavy rain while operating the machine, immediately lower the platform completely to a safe and stable position, and disconnect all power sources so as to avoid personal injury or machine damage.
- Comply with the national or regional provisions covering minimum safe distance from live conductors. In absence of such provisions, comply with the specifications in the table below to keep a minimum safe distance from power lines, electrical equipment or any live (bare or insulated) components. The minimum safe distance must take into account factors such as machine movement and the swinging or sagging of power lines.
- If an insulating partition rated for the voltage of the power lines is installed, the minimum safe distance can be reduced. Such partitions may not be part of the machine or fixed on the machine. The reduction in the minimum safe distance due to insulating partitions must comply with the relevant national or local regulations.
- Do not use the machine as a ground wire during welding and polishing operations.

Table 2-1 Minimum Safe Distance (continued)

Voltage (Phase to Phase, kV)	Minimum safe distance m (ft)
501-750	10 (32.8)
751-1000	13 (42.7)

⚠ DANGER

Do not operate the machine or transport personnel with the machine within access-restricted areas with live electrical equipment.

Table 2-1 Minimum Safe Distance

Voltage (Phase to Phase, kV)	Minimum safe distance m (ft)
0-50	3 (9.8)
51-220	4 (13.1)
221-500	5 (16.4)

Tripping and Fall Hazards

WARNING



- Before operating the machine, ensure that the platform guardrails are properly installed and that the platform gate is closed and properly secured.
- Operators on the platform must wear the safety belt properly and secure the safety belt to the specified anchorage point with the hook. Each anchorage point should only be used by one person.
- Only enter and exit the platform through the platform gate, never through the scissor, and extra care should be taken. Before entering and exiting the platform, make sure the platform is fully lowered. When entering and exiting the platform, face the platform and maintain three points of contact with the machine, with both hands and one foot or both feet and one hand.
- Both feet must be securely placed on the platform floor at all times. It is forbidden to sit, stand or climb on the platform guardrails.
- Never use ladders, boxes, steps, boards, or similar items on the platform to extend your reach.
- Do not allow oil, sludge or other slippery substances to remain on work shoes and platform floor.
- Keep the platform floor unobstructed.

Tipping Hazard

WARNING



- Before driving the machine onto any ground, bridge, truck or other surface, check if the loading capacity of the surface is sufficient to support the machine (machine weight + platform load). Do not drive the machine on any surfaces or edges that are not capable of fully supporting the machine.
- Operators must familiarize themselves with the ground conditions of the work area before commencing work.
- Do not operate the machine on moving surfaces or vehicles.
- The total weight of personnel, devices and materials on the platform may not exceed the platform's rated load capacity, and all loads must be kept within the designated range of the platform.
- The machine must not be driven on slopes, steps or arched surfaces that exceed the maximum gradeability of the machine.

WARNING



- Do not use the tilt alarm as a level indicator. The tilt alarm on the platform will only sound when the machine is severely tilted.



- When the platform is raised, if the tilt alarm sounds, lower the platform carefully, and do not modify the level switch or limit switch.




- Do not drive the machine on uneven or soft surfaces or slopes that exceed the maximum gradeability of the machine or under other hazardous conditions with the platform raised.



- The platform can only be raised or extended when the machine is on firm, flat ground.



- When the machine is traveling on uneven ground, or on other rough ground with gravel, or near cave openings, steep slopes, etc., be careful and reduce the speed.



- Do not push or pull any objects outside the platform.

- Never push or pull other equipment or objects with the platform or scissor arm.

- Do not place or attach any suspended load on or to any part of the machine.

- Do not place any load outside the perimeter of the platform.

- Using the machine as a hoist or crane is strictly prohibited.

- Never attach the machine or any part of it to any adjacent object.

- Do not operate the machine while the chassis door is opened.

- When one or more tires are off the ground, first evacuate all personnel and then stabilize the machine with cranes, hoists, forklifts, or other suitable equipment.

WARNING

- Without written authorization of the manufacturer, it is forbidden to modify, remove or install any parts, including counterweights, which may affect the safety and stability of the machine.
- Do not replace critical parts that affect the stability of the machine with parts of different weight or specifications. For example, batteries not only provide power, but also serve as a counterweight, and are crucial for maintaining the stability of the machine.

WARNING



- If the machine can be used outdoors, do not operate the machine when the wind speed exceeds 12.5 m/s (28 mph) (including gust). Please refer to the Beaufort wind force scale in the table below. Factors that affect wind speed include: the height of the platform, surrounding terrain, and local weather conditions, such as wind speed at height, which may be much higher than at ground level.
- Wind speeds may change at any time. Always consider the impending weather conditions, the time needed to lower the platform, and methods to monitor the current and potential wind conditions.
- When operating the machine outdoors, do not carry items with a large surface area on the platform, do not cover the surface of the platform or load, and never use additional items to increase the surface area of the platform or load. Adding such additional items will increase the exposure of the machine to the wind. Increasing the windward area will lead to reduced machine stability.

Table 2-2

BEAUFORT SCALE	WIND SPEED		DESCRIP- TION	SURFACE CONDITIONS
	METERS/ SECOND	MILES/ HOUR		
0	0-0.2	0-0.5	Calm	Calm. Smoke rises vertically.
1	0.3-1.5	1-3	Light air	Direction of wind shown by smoke drift.
2	1.6-3.3	4-7	Light breeze	Wind felt on exposed skin. Leaves rustle.
3	3.4-5.4	8-12	Gentle breeze	Leaves and small twigs in constant motion.
4	5.5-7.9	13-18	Moderate breeze	Raises dust and loose paper. Small branches move.
5	8.0-10.7	19-24	Fresh breeze	Small trees sway.
6	10.8-13.8	25-31	Strong breeze	Large branches in motion. Whistling heard in telegraph wires. Umbrella used with difficulty.
7	13.9-17.1	32-38	Near gale	Whole trees in motion. Inconvenience felt when walking against the wind.
8	17.2-20.7	39-46	Gale	Twigs break from trees. Cars veer on the road.
9	20.8-24.4	47-54	Strong gale	Slight structural damage.

**DANGER**

If wind speed exceeds 12.5 m/s (28 mph) after the platform has been raised, the platform should be retracted immediately, all power sources should be disconnected, and the machine should be stopped.

Collision and Crushing Hazards

 WARNING	
	All operators and other personnel in the work area must wear approved safety helmets.
	Keep all parts of the body within the platform guardrails during operation.
	Care should be taken at all times to avoid contact with stationary (built-up structures etc.) objects or moving objects (vehicles, cranes etc.) to prevent obstacles from hitting or interfering with control components or personnel on the platform.
	During operation, make sure to check the clearance and obstacles above, around and below the platform.
	Be aware of the field of vision and potential blind spots when moving or operating the machine. Observers should be put in place in case the field of vision is obstructed.
	Pay attention to the position of the extending platform while moving the machine.
	Make sure there are no persons and/or obstacles below the platform before lowering the platform.
	Do not place hands, arms, or other body parts near areas where they may be crushed.
	Do not work under the platform or near the scissor arm if the safety arm has not been properly set up.
	Ensure that operators of other equipment in the vicinity working at height and on the ground are aware that this MEWP is in operation.
	Limit travel speed based on ground conditions, congestion, ground slope, position of personnel, and other factors.
	Understand braking distances at all travel speeds. When traveling at high speed reduce the travel speed before stopping.
	Do not use the high speed setting when traveling in areas with

 WARNING
limited or enclosed spaces or when reversing. Before releasing the brake, the machine must be placed on a horizontal surface or secured.

2.4 TOWING, HAULING AND LIFTING SAFETY

For towing and dragging procedures, refer to the **Emergency Towing** section of this manual. For transport and lifting procedures, please refer to the **Transport and Lifting** section of this manual.

WARNING



- Except in case of emergency situations, machine malfunction, power loss or loading/unloading, it is strictly prohibited to tow or drag the machine.
- When towing or dragging the machine, comply with local policies and road traffic regulations.
- Before towing, dragging or lifting operations, make sure that the machine is in stowed condition, the machine has no loose or un-fixed parts, and no tools are on the platform.
- Only the lifting points/rigging equipment lashing points on the chassis may be used to tow, haul or lift the machine. Ensure that the machine lifting points/rigging equipment lashing points and their rigging equipment are intact and that the belt or rope to be used has sufficient load strength.
- When towing, hauling or lifting the machine, no persons are allowed on the platform.
- Before loading/unloading the machine, ensure that the transport vehicle is parked on level ground, that the loading surface of the transport vehicle has sufficient capacity/strength to support the machine, and that the slope of the ramp used for driving the machine onto the vehicle does not exceed the maximum gradeability of the machine.
- When loading/unloading the machine, the transport vehicle must be secured to prevent it from moving.
- The wheels should be locked after the machine is loaded to prevent it from moving.
- The machine can only be lifted from the specific position with lifting equipment with sufficient lifting capacity. Care should be taken to prevent the machine from colliding with surrounding objects.

2.5 MAINTENANCE SAFETY

Unsafe Maintenance Hazards



WARNING



- Before performing any adjustment or service operations, power off all control units and ensure that all moving parts are safely secured and cannot move unintentionally.
- Before performing any adjustment or service operations, ensure that the scissor arms are stowed, and do not carry out maintenance with the scissor arms raised. If maintenance must be carried out with the scissor arms raised, take appropriate protective measures to avoid dangerous conditions.
- When lifting or moving heavy parts of the machine, use equipment with sufficient capacity, and never place heavy objects in unstable positions after moving.
- When machine parts are lifted by other equipment, ensure that there are no persons under and/or around the equipment.
- When striking brass rods with a mallet, make sure to wear eye protection.
- If you need to replace parts, use only original parts specified by Sinoboom.
- Do not wash the machine with water. The machine contains electronic components such as sensors, which may fail or operate erratically after water ingress. If it is necessary to wash with water, turn off the main power switch before proceeding. Only turn the power back on after ensuring the machine is completely dry.
- Make sure the machine is turned off before using flushing equipment (such as a high-pressure water gun) to clean the machine. Do not direct water or steam ejected from the flushing equipment at electrical components, as this may cause short-circuits or electrical shocks.
- After maintenance is completed, thoroughly clean up any spilled

WARNING

oil, and avoid allowing it to be spilled on the ground.

- After maintenance is completed, immediately wash off any oil that may have come into contact with your skin.

Welding and Grinding Operation Hazards

WARNING



- Welding, grinding and polishing operations must follow the appropriate local safety procedures.
- Before performing welding, grinding and polishing operations, turn off the machine's power, and ensure that all wires or cables are connected correctly.
- Do not use the machine as a ground wire during welding and grinding operations.
- Always make sure that all power tools are placed completely within the perimeter of the platform. Do not hang the cords of power tools on the guardrail of the platform or in any work area outside the platform, and do not hang the power tools directly by their cords.

Fire and Explosion Hazards

WARNING



- Do not operate the machine, charge the battery or refuel the machine in places where potentially flammable or explosive gases may be present.
- Refueling and charging should be carried out in a well-ventilated place without flames, sparks, and other hazards that may cause fire or explosion.
- For engine-powered machines, do not refuel the machine while the engine is running.
- Never spray ether or other starting agents into glow-plug-equipped engines (engine-powered machines).
- Never touch the battery terminals or cable clamps with tools that can generate sparks.
- Only approved non-flammable cleaning solutions should be used on the machine.

Battery Hazard

WARNING



- Be sure to read and adhere to the battery manufacturer's recommendations on proper battery use and maintenance procedures.



- Individuals without adequate professional qualification should not repair and maintain the battery system, otherwise this may cause personal injury or damage to the battery system.



- Individuals without adequate professional qualification should not modify parameters, signal lights, etc. during the operation of the battery system, otherwise this may cause personal injury or damage to the battery system.



- Always wear goggles, protective gloves and protective clothing, and remove all rings, watches and other accessories before servicing the battery. Contact with live circuits may result in death or serious injury.



- Before replacing the battery, be sure to select an appropriate number of personnel and suitable lifting methods.

- It is forbidden to modify the battery system without approval to avoid serious accidents.

- When maintaining electrical components, the battery should be disconnected.

- Do not place tools or other metal objects across the two terminals of the battery.

- The battery charger can only be connected to a grounded three-wire AC power outlet. Make sure the charger is working properly before charging. Do not connect the battery directly to a power outlet.

- If the battery becomes hot, deformed, leaks, emits an unusual smell, or produces smoke during use, stop using the battery immediately and report to the relevant maintenance personnel promptly.

- Batteries contain sulfuric acid and can produce explosive

WARNING

mixtures of hydrogen and oxygen. Keep any materials (including cigarette/smoking materials) that can cause sparks or flames away from batteries to prevent explosion.

- Never touch the battery terminals or cable clamps with tools that can generate sparks.
- Never charge the battery in direct sunlight. The battery should be charged in a well-ventilated place.

CAUTION



- Avoid spilling battery acid or allowing it to come into contact with unprotected skin. If battery acid spills, use water mixed with bicarbonate (baking soda) to neutralize the acid. In case of contact with battery acid, rinse the acid off immediately with plenty of water and seek medical attention promptly.

- Always keep the battery upright. If the battery is placed on its side or at an angle, liquid may spill from the battery.

- Discarded batteries can be hazardous, and must not be treated like regular waste. If you need to discard them, please contact a battery recycling company.

NOTICE

- Please use the charger provided by the manufacturer to charge the battery.
- The charging process must be completed in full. Frequent intermittent charging can damage the battery.
- The battery is only suitable for use with the equipment it was provided with at the time of manufacture. Do not use the battery for other purposes.
- Do not reverse the positive and negative terminals of the battery for use.
- Do not short-circuit the positive and negative terminals of the battery system.
- Do not place objects or tools on the battery to prevent short circuiting it.
- Do not strike, throw, step on, or hit the battery with sharp objects.
- Do not immerse the battery in water, acidic, alkaline or salty solutions, and protect the battery from rain.
- The battery should be fully charged immediately after each use of the machine, then the machine power switch should be turned off.

NOTICE

Battery over-discharge (continued use of battery with level of less than 10%) or battery under-voltage caused by long-term non-charging (battery with level of less than 10% not charged for more than three days), resulting in battery capacity attenuation and failure, are not covered by the warranty.

This Page Intentionally Left Blank

3 RESPONSIBILITIES OF RELEVANT PARTIES

3.1 OWNER'S (OR LESSOR'S) RESPONSIBILITIES

- The owner (or lessor) is obliged to help the user understand all the instructions in the manual.
- The owner (or lessor) should provide the latest manuals or replace missing or damaged decals. To obtain the most current machine manuals please contact Sinoboom or its authorized agents.
- The owner (or lessor) should comply with local regulatory requirements related to the use of the machine.

3.2 EMPLOYER'S RESPONSIBILITIES

- The employer must ensure that the operator is properly trained and qualified to operate the machine.
- The employer should ensure that the user is healthy and has good judgment, sense of cooperation and psychological qualities.
- The employer has the responsibility to ensure that signalmen have good visual and auditory judgment, master standard command signals and send clear and accurate signals, and have sufficient experience to identify hazards and inform operators to avoid hazards in time.
- The employer should clarify the corresponding safety responsibilities to each operator and require them to report unsafe factors to the supervisor timely.

3.3 TRAINER'S RESPONSIBILITIES

- The trainer must be accredited by Sinoboom, have comprehensive knowledge training on the machine, and must have the required skills related to machine repair and maintenance.
- The trainer must conduct training in an open area free of hazards until the trainees acquire the ability to safely control and operate the machine.

3.4 USER'S RESPONSIBILITIES

- The user must be properly trained on MEWP, and authorized.
- The user must carefully read and fully understand this manual and the decals on the machine.
- The user must report to the owner (lessor) all anomalies that may cause the machine to work abnormally or have potential dangers, and if possible, correct the abnormal situation promptly while ensuring safety.
- The user must be fully aware of the content and procedures of the respective operation.
- The user must be familiar with and comply with signal instructions and operation requirements in emergency situations.
- The user must be vigilant in observing for any hazardous conditions and promptly report any dangers to other operators and signal personnel. This includes situations such as high-voltage lines, unrelated personnel, and unfavorable ground conditions.
- The user must stop using the equipment if it is not functioning properly or if a hazardous condition arises.

This Page Intentionally Left Blank

4 TECHNICAL PARAMETERS

4.1 MACHINE SPECIFICATIONS

Table 4-1

Item			Metric	Imperial
Product Category				
Battery type			Maintenance-free lead-acid battery	
Travel drive type			AC motor	
Dimensions				
Max. platform height			5.8 m	19 ft
Max. working height			7.8 m	25 ft 7 in
Maximum horizontal reach			0.9 m	3 ft
Overall length – stowed	Folding platform	Guardrails folded	1.8 m	5 ft 11 in
		Guardrails unfolded	1.8 m	5 ft 11 in
	Quick folding platform	Guardrails folded	1.9 m	6 ft 2.8 in
		Guardrails unfolded	1.8 m	5 ft 11 in
Overall width – stowed			0.81 m	2 ft 7.9 in
Overall height – stowed	Folding platform	Guardrails folded	1.88 m	6 ft 2 in
		Guardrails unfolded	2.14 m	7 ft
		Guardrails unfolded – AU&NZ platform	2.00 m	6 ft 6.7 in
	Quick folding platform	Guardrails folded	1.97 m	6 ft 5.6 in
		Guardrails unfolded	2.14 m	7 ft
Wheelbase			1.334 m	4 ft 4 in
Track width			0.71 m	2 ft 4 in
Ground clearance (with pothole protection retracted)			0.075 m	3 in
Ground clearance (with pothole protection deployed)			0.024 m	0.95 in
Platform dimensions (L×W×H)			1.64 m×0.76 m×1.1 m	5 ft 4.6 in×2 ft 6 in×3 ft 7 in
AU&NZ platform dimensions (L×W×H)			1.64 m×0.76 m×0.96 m	5 ft 4.6 in×2 ft 6 in×3 ft 1.8 in

Table 4-1 (continued)

Item	Metric	Imperial
Performance		
Rated platform capacity	230 kg	507 lb
Maximum load capacity of extending platform	120 kg	265 lb
Maximum number of occupants (indoor/ outdoor)	2 persons/1 person	
Drive speed (stowed)	0 ~ 4 km/h	0 ~ 2.5 mph
Drive speed (raised)	0 ~ 0.5 km/h	0 ~ 0.3 mph
Platform lifting time (unloaded)	25 ~ 30 s	
Platform lowering time (unloaded)	25 ~ 30 s	
Gradeability (2WD)	25%	
Maximum allowable inclination (front-rear/ left-right)	3°/1.5°	
Turning radius (inside/outside)	0 m/1.62 m	0 ft/5 ft 3.78 in
Tire size (diameter×width/type)	323×100 mm/solid	12.7×4 in/solid
Maximum operating noise level	72 dB	
IP rating	IP 54	
Maximum total vibration on the platform	2.5 m/s ²	
Maximum whole body vibration value (WBV)	0.5 m/s ²	
Power		
Drive x steer	2 WD × 2 WS	
Battery specifications (voltage, capacity, discharge time) – lead-acid battery	24 V, 220 Ah, 20 hr	
System voltage	24 VDC	
Control voltage	24 VDC	
Charger (input voltage/output current)	100 - 240 V AC/30 A	
Drive motor (voltage/power) – AC	24 V /0.6 kW	
Weight		
Gross weight (indoor/outdoor)	1600 kg	3527 lb
Ground bearing data		
Maximum tire load	700 kg	1543 lb
Ground pressure	1230 KPa	178 psi
Environment		
Maximum allowable lateral force (indoor/ outdoor)	400 N/200 N	90 lbf/45 lbf
Maximum allowable wind speed (indoor/ outdoor)	0 m/s/12.5 m/s	0 mph/28 mph

Table 4-1 (continued)

Item	Metric	Imperial
Maximum allowable altitude	1000 m	3280 ft
Allowable ambient temperature range (lead-acid battery)	-10° C to 40° C	14°F ~ 104°F
Maximum allowable relative humidity	90 %	
Storage environment	Store at -20°C to 50°C (-4°F to 122°F) in a well-ventilated environment with 90% relative humidity (max.) (20°C [68°F]), protected from rain, sun, corrosive gas, flammable or explosive materials.	

Note:

- a) The platform height plus the operator height (assumed to be 2 m/6 ft 7 in) equals the working height.
- b) In different areas, lubricants should be added in accordance with the ambient temperature.
- c) In cold weather, auxiliary devices are needed to start the machine.
- d) The ground bearing data is approximate, without considering different options, thus it is applicable only when taking an adequate safety factor into account.
- e) Rated platform load capacity refers to the maximum allowable load on the platform, including the weight of persons, materials, tools, accessories and other objects.
- f) It is recommended not to use lead-acid batteries in ambient temperatures below 0° C, otherwise the battery capacity will decay rapidly and the battery life will be reduced.

4.2 FUNCTION SPEED

Table 4-2

Item	Parameter
Raise the platform	25 ~ 30 s
Lower the platform	25 ~ 30 s
Travel in high gear – stowed	24.5 ~ 30 s
Travel in low gear - stowed	49 ~ 60 s
Travel - operating	195 ~ 237 s
Braking distance	S≤0.4 m (1.31 ft)

- a) The function speed depends on the start and end point of the movement rather than the controls/ switches.
- b) The drive speed test results will vary with tires of different specifications.
- c) All speed tests should be conducted from the platform controller. Test results will differ if tested from the ground controller.

Test requirements:

Raise the platform: With the platform unloaded, raise the platform (with the scissor arms from fully retracted position to fully raised position). Perform this maneuver for two times.

Lower the platform: With the platform unloaded, lower the platform (with the scissor arms from fully raised position to fully retracted position). Perform this maneuver for two times.

Travel in high gear - stowed: With the machine stowed on a level surface, switch to high gear, and push the travel joystick to the maximum travel distance to drive the machine forward and reverse for 30 m (98.4 ft) respectively for two times.

Travel in low gear – stowed: With the machine stowed on a level surface, switch to low gear, and push the travel joystick to the maximum travel distance to drive the machine forward and reverse for 30 m (98.4 ft) respectively for two times.

Travel - operating: With the machine operating on a level surface, push the drive joystick to the maximum forward position to drive the machine forward and reverse for 30 m (98.4 ft) respectively for two times.

Braking distance : As described in the “travel in high gear - stowed” test requirements, once the machine reaches the maximum drive speed, immediately release the control handle (starting timing) until the machine stops. Perform this maneuver for two times.

Note: For Japan models, the machine cannot travel while elevated to operating position.

This Page Intentionally Left Blank

5 PRE-OPERATION INSPECTION

A pre-operation inspection must be performed before each operation, before resuming operations, and before changing operators, as well as after each repair. Please carefully check each item according to the content of this section.

5.1 BASIC MACHINE COMPONENTS




Fig. 1

Table 5-1

1. Platform extension	2. Platform controller	3. Harness anchorage point
4. Main platform	5. Scissor assembly	6. Lift electric actuator
7. Rear wheel (non-steering wheel)	8. Ground controller	9. Drive motor & reducer
10. Front wheel (steering wheel)	11. Charger	12. Power handle
13. Battery	14. Charger plug cable	

5.2 MACHINE POSITIONS

The machine positions/states covered in this manual are stowed position, transport position, operating position, and non-operating position. Each position is described in detail below:

- **Stowed position:** the scissor arms are fully retracted.
- **Transport position:** the scissor arms and the platform extension are fully retracted.
- **Operating position (elevated):** the scissor arms are elevated until disengaged from the down limit switch.
- **Non-operating position:** the scissor arms are not disengaged from the down limit switch.

Notes: when the scissor arms are disengaged from the down limit switch, the platform height (from the ground to the platform floor) shall be: 2.3 ± 0.3 m (7 ft 7 in $\pm$ 12 in).

5.3 PRE-START TEST

WARNING

If any damage, malfunction, or unauthorized modifications differing from the factory state are found with the machine, it should be immediately tagged and shut down. Report the fault to the relevant maintenance personnel and do not operate the machine until safe operation can be guaranteed.

The pre-start test shall include the following:

1. Cleanliness – check all surfaces of the machine for leaks (battery electrolyte, etc.) or foreign objects.
2. Structure – check whether there are any abnormalities in the equipment structure, such as dents, damage, cracks in welds or structural components, severe rust, severe corrosion, etc.
3. Operation Manual and Maintenance Manual – ensure that the Operation Manual and Maintenance

Manual are intact, easy to read, and stored in the manuals storage box on the platform.

4. Decals and nameplate – ensure that labels and the nameplate are in place, intact, accurately located and visible.

WARNING

Do not operate the machine if any label or nameplate is missing or worn.

5. Maintenance – ensure that maintenance has been completed on the machine in accordance with the maintenance inspection requirements specified in the Maintenance Manual.
6. Battery – charge the battery as required. The electrolyte level, if adjustable, must be kept at an appropriate height.
7. Options/accessories – if the machine is equipped with any options/accessories, consult this manual and the supplemental manuals for options/accessories for inspection, operation and maintenance instructions.
8. Machine components – in addition to checking other stated items, check the following components to ensure that they are correctly installed and firmly attached without loose, missing or altered parts and visible damage, leakage or excessive wear, etc., and that all components are in their original positions and normal operating position.
 - 1) Platform assembly and gate – the platform extension shall extend and retract normally and be secured firmly; all wire rope safety pins (if equipped) for supporting the platform shall be installed properly. Ensure that the rope anchorage points are safe and reliable with only one person per anchorage point; make sure the latches and hinges are in normal working states, that the platform gate opens and closes properly, is not bent or damaged, and that the surrounding area is free of obstacles. The gate should remain closed at all times, except for entering/exiting the platform and loading/unloading materials.

- 2) Ground controller and platform controller – ensure that all control switches are turned off, that joysticks are in the neutral position and can return to the neutral position after activated and released, and that all control markings are visible.
- 3) Scissor assembly;
- 4) Tire assembly – ensure that the tire assembly is firmly secured and wheel nuts are not loose or missing; check for worn tread, cuts, breakage or other abnormalities;
- 5) Drive motor.
- 6) Brake device and brake release function.
- 7) Platform emergency lowering function.
- 8) Tire steering linkage and wheel carrier.
- 9) Pothole protective device – extend and retract normally.
- 10) Electrical parts such as limit switches and wire harnesses.

NOTICE

Make sure to check the platform floor area, as inspection of this area may uncover conditions that could cause personal injury or machine damage.

5.4 FUNCTIONAL TEST

Before performing a functional test:

- Choose a firm, flat and level test area.
- Make sure the test area is free from obstructions.
- Be sure that the batteries are well connected.



WARNING

If any switch/handle returns to the neutral position but the corresponding movement does not stop, push in the emergency stop button to stop the machine.

Follow these steps to perform a functional test:

1. With no load applied on the platform, turn the ground/platform control selector switch on the turntable controller to the ground control position, pull out the emergency stop button on the ground controller, and perform the following tests from the ground controller:
 - 1) Make sure that the screen is turned on and shows no error message during the entire functional test.

- 2) Make sure that when the emergency stop button on the ground controller is pressed, the controller is powered off, the machine cannot be started and no functions operate.
 - 3) Activate any action switch without activating the enable switch, and the corresponding action cannot operate.
 - 4) Activate the enable switch and any action switch at the same time, and the corresponding action shall operate normally. Release the switch/handle after one action is performed – the corresponding action should be stopped reliably and safely.
2. Set the “ground/platform control selector switch” on the ground controller to the platform control position, pull out the emergency stop button at the ground controller and platform controller, and perform the following tests from the platform controller:
- 1) Make sure that when the emergency stop button at the platform controller is pressed, the platform controller is powered off, and no function can be activated from the platform controller.
 - 2) Make sure that the horn sounds properly when the horn button is pressed.
 - 3) Activate any action switch/handle without activating the enable switch – the corresponding function cannot be activated.
 - 4) Activate the enable switch and any action switch/handle at the same time, and the corresponding action shall operate normally. Move the switch/handle to the neutral position after an action is performed – the corresponding action should stop reliably and safely.
- Note:** When the travel joystick is released, the brake must be able to hold the machine on any slope within the maximum gradeability reliably without sliding.
- 5) In platform lift and lower mode, the joystick controls the platform lifting and lowering functions, while the travel and steer functions will be disabled.
 - 6) In drive and steer mode, the joystick controls travel and steer functions, while the platform lifting and lowering functions will be disabled.
 - 7) With the machine in non-operating position and the low speed travel mode not activated, activate the travel function and push the travel joystick to full drive position, and the machine will travel at high speed.
 - 8) With the machine in non-operating position, push upward the high/low travel speed selector switch, and the machine will start to travel at low speed (if equipped with Sinoboom control system).

- 9) With the machine in non-operating position, press the low speed button, and the machine will start to travel at low speed (if equipped with DTC or Kuanhui control system).
- 10) With the machine in operating position, the travel speed of the machine will be reduced to the speed for the raised position automatically.

This Page Intentionally Left Blank

6

CONTROLLERS AND INDICATORS

This chapter provides a brief introduction of switches, handles and screens at the ground controller and platform controller. Refer to the **Operation Instructions** section for a detailed description.

6.1 GROUND CONTROLLER

NOTICE

The manufacturer cannot directly control the application and operation of the machine. Users and operators are responsible for complying with the applicable safety specifications.




Fig. 1

Table 6-1

No.	Name	Description
1	Self-resetting fuse	Provides overcurrent protection
2	Emergency stop button	When pulled to the “ON” position the machine can be started normally; pushing the button to the “OFF” position will deactivate the controller, the machine cannot be started and no functions can be activated.
3	Neutral/OFF position	/
4	Platform control position	/
5	Key switch (ground/platform control selector switch)	Set the switch to neutral position: the machine will be powered off.

Table 6-1 (continued)

No.	Name	Description
		Turn the switch to “platform control position”: all functions will be operative only at the platform controller; the ground controller will not work. Turn the switch to “ground control position”, and all functions will be operative only at the ground controller while the platform controller will not work.
6	Ground control position	/
7	Main controller	/
8	Ground display	ECU menu selection/setting interface
9	Return key	Go to the previous interface of the ground display screen
10	Up arrow key	Scroll up the ground display screen
11	Enable key	Press and hold the Enable key; all functions will be enabled to operate.
12	Platform Down key	Control platform down function
13	Platform Up key	Control platform up function
14	Enter key	Enter the next interface of the ground display screen
15	Down arrow key	Scroll down the ground display

6.2 PLATFORM CONTROLLER (SINOBOOM CONTROL SYSTEM)




Fig. 2 Platform Controller (Sinoboom Control System)

Table 6-2

No.	Name	Description
1	Enable switch	Move and hold the switch – all functions will be enabled to operate.
2	Left turn thumb button	Press the button to steer the machine to the left.
3	Right turn thumb button	Press the button to steer the machine to the right.
4	Joystick	In platform lift and lower mode, pushing this joystick forward/back will raise/lower the platform; In drive and steer mode, pushing this joystick forward/back will drive forward/back.
5	High/low travel speed selector switch	Move the switch up to enable low travel speed mode.

Table 6-2 (continued)

No.	Name	Description
6	Indoor/outdoor mode selector switch (if equipped)	Move the switch up to enable outdoor mode; Move the switch down to enable indoor mode.
7	Emergency stop button	Pull out the button to the ON position – the platform controller will function normally; press the button to the OFF position, the platform controller will be powered off and no function can be activated from the platform controller.
8	Horn button	Press the button to sound the horn.
9	Platform display	Display battery level, alarm message and fault codes.
10	Lift/drive and steer function enable switch	Move the switch up to enable platform lift/lower mode; Move the switch down to enable travel and steer mode.

7 OPERATION INSTRUCTIONS

7.1 GENERAL

This mobile elevating work platform is used to transport tools to work locations and for performing tasks on the work platform. This machine has two controllers: ground controller and platform controller.

WARNING

- Except in case of emergency, it is forbidden to perform operations from the ground if any person is still on the platform.
- If any switch/handle returns to the neutral position but the corresponding movement does not stop, push in the emergency stop button to stop the machine.
- The replacement joystick of the platform controller must be of the same brand as the original one, otherwise the machine functions may be impeded or accidents may occur.


7.2 GRADEABILITY

Gradeability refers to the maximum allowable slope angle the machine can achieve on firm ground with sufficient traction, the platform in stowed position and occupied by only one person. Gradeability will decrease when the load on the platform increases.

WARNING


Do not drive the machine on slopes exceeding the machine's maximum gradeability.

The gradeability includes uphill/downhill as well as lateral slope capability. Uphill/downhill gradeability of this machine:



Uphill/downhill: 25 %/14 °

Lateral slope limit:



Lateral slope: 25 %/14 °

7.3 ACTIVATING THE MACHINE

NOTICE

Before activating the machine, make sure that:

- The power switch is turned on.
- The lithium battery, if acting as the power source, is activated (refer to **Activating Lithium Battery**).

Note: The first start must always be done from the ground control position.

Start machine from the ground

1. Turn the ground/platform control selector switch at the ground controller to the ground control position.
2. Pull out the emergency stop button at the ground controller to the ON position.
3. The turntable screen will be turned on and should show no error message. All functions will be operative only at the ground controller; the platform controller will not work.

Start machine from the platform

1. Turn the ground/platform control selector switch at the ground controller to the platform control position.
2. Pull out the emergency stop button at the ground controller to the ON position.
3. Pull out the emergency stop button at the platform controller to the ON position.



WARNING

Before pulling out the emergency stop button at the platform controller, ensure the joystick is in the neutral position; if not, do not operate the machine.

4. The platform screen will be turned on and should show no error message. All functions will be operative only at the platform controller; the ground controller will not work.

7.4 CHARGING THE BATTERY

There are three types of batteries that may be used in this machine: Lead acid battery, maintenance-free lead acid battery, and lithium battery. The latter two types do not require maintenance.

The battery level must be checked before each operation.

When the battery level is too low, the low battery alarm will be displayed on the platform display screen, and the high travel speed will be reduced. Stop the machine immediately and fully charge the battery.

NOTICE

- *The machine is delivered with a battery level less than 80%, so it is recommended that the battery is fully charged once the machine has been delivered.*
- *The charging current must not exceed the maximum allowable charging current indicated on the battery.*
- *The charging voltage must not exceed the maximum allowable voltage indicated on the battery.*
- *The battery charging temperature range is -10 °C to 45 °C. If equipped with a charging heating system, the charging temperature range is -20 °C to 45 °C.*
- *Battery over-discharge (continued use of battery with levels of less than 10%) or battery under-voltage caused by long-term non-charging (battery with levels of less than 10% not charged for more than three days), resulting in battery capacity attenuation and failure, are not covered by the warranty.*
- *It is recommended not to use a lead acid battery with an ambient temperature below 0 °C; otherwise the battery capacity will decay rapidly, and battery life will be affected.*

Charging lead-acid (maintenance required) batteries

1. Checking the battery level.

- Check the battery level on the screen of the platform controller. When the battery level is $\leq 20\%$, the low battery alarm will be triggered and the battery needs to be charged immediately. To avoid affecting the normal performance of the machine it is recommended to charge the battery when the battery level is below 30 %.
- As an alternative means of determining the battery status, open the cover on the battery and measure the density of the electrolyte. If the density of the electrolyte is less than 1.13 kg/l the battery has been over-discharged (discharge depth exceeds 80 %) and must be charged immediately. This should be avoided, as frequently over-discharging the battery will reduce its service life.

NOTICE

Measure the temperature of the electrolyte. If it exceeds 45 °C wait for the battery to cool before proceeding to the following steps.

2. Completely power off the machine.
3. Connect the plug between the battery and the charger cable. If the machine is equipped with an automatic liquid refilling system, ensure that the refilling pipe is connected.
4. Connect the battery charger to a grounded AC circuit. The indicator light will illuminate steadily once the battery is fully charged.
5. After charging is complete, disconnect the cable plug from the battery to the charger.

Charging AGM (maintenance-free)/lithium batteries

1. Check the battery level on the screen of the platform controller. When the battery level is $\leq 20\%$, the low battery alarm will be triggered and the battery needs to be charged immediately. To avoid affecting the normal performance of the machine it is recommended to charge the battery when the battery level is below 30 %.
2. Completely power off the machine.
3. Connect the battery charger to a grounded AC circuit. The indicator light will illuminate steadily once the battery is fully charged.
4. After charging is complete, disconnect the cable plug from the battery to the charger.

Description of Battery Level Indications

The battery level indication on the platform display is as follows:

Table 7-1

Platform battery level indication	State of charge	Description
	90-100 %	The battery has been fully charged.
	70 %	The battery is at 70 % of its capacity.
	50 %	The battery is at 50 % of its capacity.
	30 %	The battery is at 30 % of its capacity.
	20 %	The battery level is at 20 %, which is low. The battery should be charged immediately.
	10 %	The battery level is at 10 %, which is extremely low. The machine will move slowly. The battery should be charged immediately.

Charger LED Description

LED indicator light and digital display description:

Connect the charger to the battery and plug the charger to a standard power outlet; the charger will enter the charging mode. The following information will be displayed in sequence: AC XXX (the current AC input voltage), CPU X.XX (software version of the charger), b** (the current charging curve code).

Charging state indicator lights and digital display description:

- % (state of charge indicator light) represents the current state of charge in percent (%). For example: 10 20 30...100 (%).
- V (charge voltage indicator light) represents the current charge voltage, the number indicates the voltage value. For example: 24.0 (V).
- A (charge current indicator light) represents the current charge current, the number indicates the current value. For example: 36.0 (A).

7.5 LIFTING AND LOWERING THE PLATFORM



WARNING

If the tilt alarm is triggered, stop operation and fully lower the platform. Do not start operation again unless the tilt cause has been corrected.

Performing Operations on the Ground

- 1. Raise the platform:** Press and hold the Enable key on the joystick and press the Platform Up key. The platform should rise and the pothole protective device should deploy.
- 2. Lower the platform:** Press and hold the Enable key on the joystick and press the Platform Down key. The platform should descend and the pothole protective device should retract.

Performing Operations on the Platform

- Activate platform lift and lower mode - Sino-boom control system:** Move up the lift/drive & steer function enable switch, the indicator above the switch will illuminate, the machine will enter the platform lift and lower mode.

Note: When performing operation from the platform, the lifting speed of the platform is in direct proportion to the travel distance of the joystick. The shorter the travel distance, the slower the speed.

- 1. Raise the platform:** Press and hold the enable switch on the joystick and push the joystick forward. The platform should rise and the pothole protective device should deploy.
- 2. Lower the platform:** Press and hold the Enable switch on the joystick and pull the joystick back. The platform should descend and the pothole protective device should retract.

Note: While using the platform controller to lower the platform in the operating position, after the platform has reached the non-operating position, it will automatically stop lowering. The operator must restart the platform lowering function (release the joystick, return to the neutral position, and then turn the joystick again). The platform will continue to descend after 5 s.

7.6 TRAVELING

WARNING

- The machine must not travel with the platform raised unless it is on a firm and flat surface without exceeding the maximum allowable climbing angle.
- The machine must not be driven on slopes, steps or arched surfaces that exceed the maximum gradeability of the machine.
- Extreme care must be taken when driving the machine in reverse or with the platform raised.
- When driving the machine in potentially dangerous situations such as driving on slopes or reversing, operate the handle in small increments to avoid danger due to excessive speed.

Activating Drive and Steer Mode

- Sinoboom Control System: Move the lift/drive and steer function enable switch down, the indicator under the switch will illuminate. The machine will enter drive and steer mode.

Driving Forward and Reverse

Note: The travel speed is in direct proportion to the travel distance of the joystick. The shorter the travel distance, the slower the speed.

1. Activate the drive and steer mode.
2. **Driving forward:** Press and hold the enable switch on the joystick and push the joystick forward. The machine will move forward.
3. **Driving reverse:** Press and hold the enable switch on the joystick and pull the joystick back. The machine will move in reverse.
4. **Braking:** While the machine is traveling: when the joystick is released the machine should stop.

Steering While Traveling

1. Activating drive and steer mode.
2. **Steer left:** Press and hold the Enable switch on the joystick, push the joystick forward and press the left button on the top of the joystick with your thumb – the machine will steer left.
3. **Steer right:** Press and hold the Enable switch on the joystick, push the joystick forward and press the right button on the top of the joystick with your thumb – the machine will steer right.

Traveling on Slopes

WARNING

The machine must not be driven on slopes, steps or arched surfaces that exceed the maximum gradeability of the machine.

Before traveling on a slope, please determine:

1. The machine's maximum gradeability.
2. The slope grade. To determine the slope grade:
 - Use a suitable carpenter's ruler, a straight piece of wood and a tape measure.
 - Measure the height (H) and length (L) of the slope.




Fig. 1

- Slope grade= $H/L \times 100\%$.

WARNING

Do not drive the machine on the maximum permissible slope for more than 2 minutes to avoid overheating the drive motor.

High and Low Travel Speed Switching

WARNING

- In a tilted condition the machine must be driven at low speed.
- Before traveling at high speeds, make sure to first observe whether the surrounding environment is safe. Otherwise, it is possible that collisions and other hazards may occur with obstacles or other people.

Sinoboom control system:

1. With the machine traveling in non-operating position, push up the high/low travel speed selector switch, the indicator will illuminate, and the travel speed will be switched to low speed.

NOTICE

With the machine in non-operating position and the high/low travel speed selector switch in neutral or lower position, activate the travel function and push the joystick, the machine will start to travel at high speed immediately, and pushing the joystick to full drive position will bring the machine to the maximum travel speed.

2. With the machine in operating position, the travel speed of the machine will be reduced to the elevated travel speed automatically.

7.7 EXTENDING AND RETRACTING PLATFORM

WARNING

- While extending the platform, do not stand on the platform extension.
- Do not lower the platform if the platform extension has not been fully retracted.
- The platform extension can be secured in three slots. Do not work on the platform extension while it has not been secured.




Fig. 2

Extend the platform:

1. Depress the pedal #1, grasp and push the guardrail of the platform extension to extend the platform extension.
2. Release the pedal #1, and insert the platform extension end into the slot #2 to secure it.

Retract the platform:

1. Depress the pedal #1, grasp and pull the guardrail of the platform extension back to retract the platform extension.
2. Release the pedal #1, and insert the platform extension end into the slot #2 to secure it.

7.8 FOLDING AND UNFOLDING PLATFORM GUARDRAILS

The platform guardrails can be folded for convenient transportation.

WARNING

- Do not raise the platform while the guardrails are folded. The guardrails must be unfolded and secured properly while the platform is lifting.
- Fold/unfold the guardrails only when the machine is stowed and the platform extension is fully retracted.
- Do not reach hands and arms near areas where they may be crushed.
- With the platform guardrails folded, if the machine is to be started from the ground with the platform controller, the operator should maintain a safe distance of at least 1 m (3 ft) from the machine.

Folding Platform

Fold down the platform guardrails:




Fig. 3

1. Remove the platform controller and its bracket. Remove the two wire rope safety pins at the front of the platform extension. Fold the front guardrail of platform extension inward.
2. Fold the guardrails on both sides of the platform extension inward.
3. Pull out the two wire rope safety pins at the access gate of the platform. Fold the access gate inward.
4. Pull out the two wire rope safety pins at the rear of the platform, and fold the guardrails on both sides of the platform inward.

Unfold the platform guardrails:

Unfold the platform guardrails in the reverse order of the fold-down instructions.

Quick Folding Platform

Fold down the platform guardrails:




Fig. 4

1. Remove the platform controller and its bracket.
2. Grasp and lift up the handles on both sides of the platform extension guardrails from the platform inside, and fold down the guardrails towards the door lock.
3. Similarly, grasp and lift up the handles on both sides of the main platform guardrails, and fold down the guardrails towards the door lock.
4. Pull out the two wire rope safety pins at the access gate of the platform. Fold the access gate inward.

Unfold the platform guardrails:

Unfold the platform guardrails in the reverse order of the fold-down instructions.

7.9 TURNING OFF AND STOPPING

1. Park the machine on a firm, flat, and level surface, and make sure the area is adequately protected.

2. Make sure that the platform is fully lowered and all panels and gates are closed and secured.
3. Remove all loads from the platform.
4. Press the emergency stop buttons on the ground controller and platform controller, and switch the ground/platform control selector switch to “neutral” position, and remove the key (if equipped).
5. Close the platform controller guard to protect the platform controller and its handles, switches and panels from damage by harsh environments.
6. If the machine will not be used for a prolonged period of time, press the power switch to OFF/pull out the power handle.

capacity. Care should be taken to prevent the machine from colliding with surrounding objects.

Transport

1. Adjust the machine to the transport position.
2. On the ground controller, switch the “ground/platform control selector switch” to “neutral” position, and remove the key (if equipped).
3. Use at least 2 ropes or belts at the lashing points shown in the figure below to securely fix the chassis to the transport vehicle, and take appropriate safety protection measures.
4. Adjust the rigging appropriately to prevent damage to the rope or belt.

7.10 TRANSPORT AND LIFTING

The mobile elevating work platform is a non-road vehicle and is not licensed for on-road use, so the machine needs to be transported and transferred by road, railway or waterway.



WARNING

Only qualified individuals may drive the machine onto or from the transport vehicle.

Before transporting and lifting the machine:

1. Determine the total weight of the machine (see machine nameplate or **Technical Parameters** section of this manual) and select the appropriate lifting equipment, rigging equipment, and transport vehicle.
2. Make sure that the machine is in transport position, the machine has no loose or unfixed parts, and that no people or any tools are on the platform.
3. Ensure that the machine lifting points/rigging equipment lashing points and their rigging equipment are intact and that the belt or rope to be used has sufficient load strength.
4. Before loading/unloading the machine, ensure that the transport vehicle is parked on level ground and that the ramp used for driving the machine onto the transport vehicle does not exceed the maximum gradeability of the machine.
5. When loading/unloading the machine, the transport vehicle must be secured to prevent it from moving.
6. The wheels should be locked after the machine is loaded to prevent it from moving.
7. Before releasing the brake, the machine must be parked on a horizontal surface or secured.
8. The machine may only be lifted from a specific position with a forklift or crane with sufficient lifting




Fig. 5 Transport Diagram

Lifting

1. Determine the center of gravity of the machine.
2. The rigging equipment must be attached to the machine's specified lifting point.

3. Adjust the rigging equipment properly to avoid damage to the machine and keep the machine level.

Diagram of Center of Gravity

X=595 mm (1 ft 11.4 in) Y=525 mm (1 ft 8.7 in)




Fig. 6 Diagram of Center of Gravity




Fig. 7 Diagram of Lifting with Rigging Equipment

A forklift may be used to lift the machine.

1. Align the forklift forks to the positions indicated by the arrows in the diagram below.
2. Drive the forklift forward to fully insert the forks into the pockets.
3. Lift the machine by 0.4 m (16 in) and then tilt the forks backward slightly to keep the machine stable.
4. Keep the machine horizontal when lowering the fork frame.




Fig. 8 Diagram of Lifting with Forklift

7.11 STORAGE

Mobile elevating work platforms should be stored in places that are protected from rain, humidity, sunlight, or corrosive gases, and that have good ventilation.

In order to ensure the machine can be operated normally after prolonged storage the following measures should be taken when storing the machine:

1. Lower the platform to the stowed position.
2. Close and lock all panels and gate locks on the machine.
3. Press the emergency stop buttons on the ground controller and platform controller, turn the ground/platform control selector switch to the Neutral position, and remove the key (if equipped).
4. Press the power switch/pull out the power handle.
5. Chock the wheels.
6. Wipe off all dust and oil from the machine to keep it clean.
7. Apply lubricating oil to parts prone to corrosion.
8. When long-term storage is required, the positive and negative terminal of the battery should be disconnected.
9. For a machine stored for more than three months, idle the machine every three months for not less than one hour each time, and clean and maintain the machine.
10. For a machine stored for more than one and a half years, a comprehensive inspection and maintenance on the machine should be carried out before use, aging seals and filter elements should be replaced as appropriate.

8

EMERGENCY PROCEDURES

This chapter describes the steps to follow in the event of unexpected situations during operation.

8.1 REPORTING ACCIDENTS

In case of any accident involving Hunan Sinoboom Intelligent Equipment Co., Ltd. products, Hunan Sinoboom Intelligent Equipment Co., Ltd. must be notified immediately. In case of any accident involving the machinery of Hunan Sinoboom Intelligent Equipment Co., Ltd., notify Hunan Sinoboom Intelligent Equipment Co., Ltd. by telephone immediately and provide all necessary details, even if the accident did not cause personal injury or property damage.

Failure to notify the manufacturer within 48 hours of the incident involving the machinery of Hunan Sinoboom Intelligent Equipment Co., Ltd. may void the product warranty.

NOTICE

Thoroughly inspect the machine and all its functions after any accident. First, test all functions from the ground controller, then from the platform controller. Ensure the machine's lifting height does not exceed 3 m (10 ft) until all damage has been repaired and all controllers operate properly.

If any switch is reset but the movement does not stop:

If any switch/handle returns to the neutral position but the corresponding movement does not stop, push in the emergency stop button to stop the machine.

8.3 EMERGENCY LOWERING

When the power source fails, the emergency lowering handle can be used as appropriate to lower the platform into place. Correct steps for its application are as follows:

1. Cut off the power supply of the machine.
2. Locate the emergency lowering handle (near the decal of emergency lowering) located at the rear of the chassis.
3. Pull out the emergency lowering handle slowly to lower the platform.




Fig. 1 Decal of Emergency Lowering

8.2 EMERGENCY OPERATION

When the operator is unable to control the machine (squeezed or trapped on the platform):

1. Other personnel can only operate the machine with the ground controller according to the operation requirements.
2. Other qualified operation personnel on the platform can operate the platform controller. If the controller is not working properly, do not continue to operate.
3. Hoists, forklifts or other equipment that meet the requirements of use can be used to transport people on the platform and stabilize the movement of the machine.

When the platform is stuck at height:

If the platform is stuck or blocked by high buildings or aerial equipment, rescue the operator on the platform first and then get the machine out.

8.4 EMERGENCY TOWING

WARNING

- Except in case of emergency situations, machine malfunction, power loss or loading/unloading, it is strictly prohibited to tow or drag the machine.
- When towing or dragging the machine, comply with local policies and road traffic regulations.
- Towing the machine on public highways is prohibited.
- The machine is not equipped with a brake for towing control, so the towing vehicle must be able to control the machine at all times, otherwise the machine may lose control, resulting in serious injury or death.
- The maximum permissible towing speed is 3 km/h (1.9 mph).
- The maximum permissible towing gradient is 25 %.
- The machine must not be towed/dragged when the brake has not been released or the machine is started.
- Before the brake is released, the machine must be parked on a horizontal surface or secured.

Method 1:




Fig. 2

Table 8-1

No.	Name
1	Cover locking screw
2	Cover
3	Brake locking screw
4	Brake

1. Place the machine on solid level ground and secure the wheels with chocks to prevent the machine from moving inadvertently.
2. Make sure that the machine is in stowed without loose or unsecured objects, and there are no people or tools in the platform and no obstacles in the surrounding area.
3. Remove 4 cover locking screws #1 and then the cover #2.
4. Remove 3 brake locking screws #3, and axially pull out the brake to disengage it from the motor shaft gear.
5. The motor brake is disengaged from the wheel drive, the wheel can rotate without power, and the machine can be towed or dragged by external force.
6. After towing, place the machine on firm, level ground and secure the wheels with chocks to prevent the machine from moving.
7. Reinstall the removed components and the brake will operate effectively.

Method 2 (for Sinoboom Control System):


1. Place the machine on firm, level ground and secure the wheels with chocks to prevent the machine from moving.
2. Make sure that the machine is stowed and has no loose or unfixed parts, and there are no people or tools in the platform and no obstacles in the surrounding passage.
3. Pull out the emergency stop button at the ground controller to the ON position.
4. Turn the key switch to the ground control position.
5. Press the Enter key to enter the ECU menu selection mode.
6. Press the Page Down key until the screen shows "System Setting", then press the Enter key.
7. Press the Page Down key until the screen shows "Brake Release", and then press and hold the Enter key for 5 s.
8. The buzzer will sound, and the message "Brake Is Released" will be shown on the display, indicating that the brakes were released successfully.
9. The machine may then be towed or dragged by an external force.

10. After towing, place the machine on firm, level ground and secure the wheels with chocks to prevent the machine from moving.
11. Turn on the machine, so the brake can be operated properly.

This Page Intentionally Left Blank

9 DECALS DIAGRAM

DECALS DIAGRAM



No.	CSA	ANSI	CE-Metric	CE-Imperial	KCS	Description	Quantity
	101089100018	101089100008	101089100010	101089100011	101089100009	General decals diagram	1
1	101048103025	101048103025	101048103025	101048103025	101048103025	LOGO SINOBOOM	2
2	101089100003	101089100003	101089100004	101089100003	101089100004	Decal - Trade name 0608ME All	2
3	216060000004	216060000004	216060000004	216060000004	/	Yellow & black hazard warning stripe tape (50mm wide)	3
4	104011100021	104011100021	104011100021	104011100021	/	Decal - Crushing hazard	2
5	101079103017	101079103017	101079103017	101079103017	101079103017	Decal - Crushing hazard	2
6	101057103024	101057103024	101058103018	101058103018	101058103018	Decal - Tire ground load of 700kg	4
7	101040103013	101040103013	/	/	/	Decal - Electrocution hazard	2
8	101012100026	101012100026	101012100026	101012100026	101012100026	Decal - Forklift pockets	6
9	101040103023	101040103023	101040103023	101040103023	101040103023	Decal - Large logo in white	2
10-1	101038100008	101038100008	101038100008	101038100008	/	Decal - No smoking or open flames	2
10-2	/	/	/	/	101038100008	Decal - No smoking or open flames	2
11-1	101012100008	101012100008	101012100008	101012100008	/	Decal - Tipping hazard	2
11-2	/	/	/	/	101012100008	Decal - Tipping hazard	1
12	101038100002	101038100002	101038100002	101038100002	101038100002	Decal - High pressure hazard	1
13	101014100013	101014100013	101014100013	101014100013	101014100013	Decal - Crushing hazard	2
14	101014100017	101014100017	101014100017	101014100017	101014100017	Decal - Refer to the manuals	1
15	101014100018	101014100018	101014100018	101014100018	101014100018	Decal - Lifting point	1
16	101016100034	101016100034	101016100034	101016100034	/	Decal - Noise level of 72dB	2
17	101079103010	101079103010	101079103010	101079103010	101079103010	Decal - Lifting point and lashing point	4
18	101014100007	101014100007	101014100007	101014100007	101014100007	Decal - Platform charging plug	1
19-1	101079103031	101079103031	101079103031	101079103031	/	Decal - Tipping hazard	2
19-2	/	/	/	/	101012100008	Decal - Tipping hazard	1
20-1	101038103017	101038103017	101041103020	101041103020	/	Decal - Tipping hazard	1

No.	CSA	ANSI	CE-Metric	CE-Imperial	KCS	Description	Quantity
20-2	/	/	/	/	101041103020	Decal – Tipping hazard	1
21	101038100007	101038100007	101038100007	101038100007	101038100007	Decal – Electrocution hazard	1
22	101077103018	101077103018	101077103018	101077103018	101077103018	Decal - Power switch	1
23	101056103027	101056103027	101056103027	101056103027	101056103027	Decal – Charging voltage and current	1
24	215050000012	215050000012	215050000012	215050000012	215050000012	Blind rivet 4x8-ZnD GB/T 12618.2	4
25	101016103010	101016103010	101079103032	101079103032	101015100026	Nameplate	1
26	101014100032	101014100032	101014100032	101014100032	101014100032	Decal - Machine serial number	2
27	101089100016	101089100016	101089100016	101089100016	101089100016	Decal - Emergency lowering	1
28	103006103014	103006103014	103006103014	103006103014	103006103014	Decal – Anchorage point	8
29	101089100001	101089100001	101089100014	101089100014	101089100014	Decal - Requirements of use (0608ME All)	1
30	101079103016	101079103016	101079103016	101079103016	101079103016	Decal – General safety instructions	1
31	101048103023	/	/	/	/	Decal - Operation instructions	1
32	103010103014	103010103014	/	/	/	Decal – Non-insulated	1
33	101040103015	101040103015	/	/	/	Decal – Annual inspection date	1
34	101089100002	101089100002	101089100015	101089100015	101089100015	Decal - Requirements of use (0608ME All)	1
35	101014100026	101014100026	101014100026	101014100026	101014100026	Decal - Safety arm	1
36	101040103008	101040103008	101040103008	101040103008	101040103008	Decal - Release brake	2
37	101040103014	101040103014	/	/	/	Decal - Detachable joystick bracket	1
38	101055103015	101055103015	104011100016	104011100016	101055103015	Decal – Emergency stop button	1
39	/	/	101089100019	101089100019	/	Decal - Handle hold position	4
40	/	/	101086103013	101086103013	/	Decal - Crushing hazard	2
41	/	/	101012100005	101012100005	/	Decal – Electrocution hazard	2
42	/	/	/	/	101012100005	Decal – Electrocution hazard	2

10 MAINTENANCE

This chapter provides the operator with additional information needed to properly operate and maintain the machine, and is only intended to assist the operator in performing routine maintenance tasks. For more comprehensive maintenance instructions, please refer to the **Inspection and Preventive Maintenance Schedule** and the Maintenance Manual.

10.1 TIRE ASSEMBLY

Checking Tires and Rims

Maintaining the tires and rims is essential for the normal and safe operation of the machine. The machine may tip over if a tire or a rim fails, so check the tires and rims each time before operating the machine and repair defective tires and rims in a timely fashion.

This machine is equipped with solid tires that do not need to be inflated.

- Check each tire for cuts, cracks, punctures and abnormal wear. Replace the tire if necessary.
- Check each rim for damage, deformation or cracked welds. Replace the rim if necessary.

Checking Wheel Nuts

The wheel nuts should be tightened before the machine is put into service for the first time and after each tire is removed. Check and tighten the wheel nuts to the specified torque every 3 months or 250 operating hours.

Replacement Requirements



WARNING

- The tires and rims on the machine have been designed and selected according to the overall performance and load stability requirements of the machine. Therefore, the model specifications, rim width, installation center surface, diameter, etc. must not be changed, otherwise this could lead to an unstable and hazardous condition.
- Wheel-specific nuts must be used that match the wheel bolts. The wheel nuts must be installed and maintained with the proper tightening torque to prevent loose rims, broken bolts and wheels loosening from the axle. Be sure to only use nuts that match the mounting angle of the rim holes.

Hunan Sinoboom Intelligent Equipment Co., Ltd. recommends the replacement tire be of the same size, ply rating and brand as the original tire. For the tire part numbers of specific machine models, please refer to the Parts Manual of the corresponding machine. If you choose not to use the replacement tires recommended by Hunan Sinoboom Intelligent Equipment Co., Ltd., the following specifications should be adhered to:

- The ply rating/rated load capacity and size should be the same as the original tire or superior to it.
- The tire tread contact width should be the same as or superior to the original tire.
- The wheel diameter, width and offset dimensions must be the same as the original tires.
- The replacement tire must be approved for the application by the tire manufacturer (including intended purpose, maximum travel speed, maximum tire load, etc.).
- Due to size differences between different tire brands, both tires on the same axle should be of the same brand.

NOTICE

Unless specifically approved by Sinoboom, do not replace foam-filled tires with pneumatic tires.

Replacing Tires

WARNING

Tighten the wheel nuts to the specified torque to prevent the wheel from loosening. Use a torque wrench to tighten the nuts. If no torque wrench is available use a socket wrench to tighten the nuts and then immediately have a service station or dealer tighten the nuts to the specified torque. Over-tightening will cause the nuts to break or permanently deform the bolt holes in the rims.

The correct steps to replace a tire are as follows:

1. Make sure the machine is in stowed position.
2. Press the main power switch/pull out the main power handle and disconnect all power sources (such as battery charger) from the machine.
3. Use a jack with sufficient load capacity to lift the machine to the appropriate height so that the wheel assembly is off the ground.
4. Use suitable lifting equipment to safely support the wheel assembly.
5. Remove the fasteners in an alternating sequence, then remove the tire.
6. Align the mounting holes of the new wheel with the corresponding mounting holes on the hub, fit the flat surface of the gasket to the mounting surface (if gaskets are used). After applying Loctite 272 threadlocking adhesive to the bolts, install the bolts in sequence, and tighten the bolts diagonally to the torque specified in **Torque Specifications**.
7. Remove the jack as needed after installation.

10.2 INSPECTION AND PREVENTIVE MAINTENANCE SCHEDULE

This section provides safety and other vital information for machine operators. To extend the service life of the machine and ensure safe operation, all necessary inspections and maintenance work must be completed before the machine is put into service.

It is crucial to develop and adhere to a comprehensive inspection and preventive maintenance program. This manual outlines the regular inspections and maintenance procedures recommended by Hunan Sinoboom Intelligent Co., Ltd. Consult your national, regional or local regulations for aerial work platforms. The frequency of the inspection and maintenance must be increased as required by environmental conditions, requirements and frequency of usage.

Pre-delivery Inspection (PDI)

The pre-delivery inspection shall be performed by qualified Sinoboom technicians.

A pre-delivery inspection shall be performed before each sale, lease or rental delivery.

Refer to the **Inspection and Preventive Maintenance Schedule** for items requiring a PDI. Refer to the corresponding section of this manual to perform inspection and maintenance procedures.

Pre-operation Inspection

A pre-operation inspection must be performed before each start or restart of work, change of operator, and after each maintenance operation. Refer to the pre-operation inspection section of the Operation Manual for detailed information. The Operation Manual must be entirely read and understood before performing the pre-operation inspection.

Regular Inspections

Regular inspections shall be performed by qualified Sinoboom technicians.

Regular inspections must be performed after the machine has been in service for 3 months or 250 hours, whichever comes first, or if it has been out of service for more than 3 months. The frequency of the inspection and maintenance must be increased as required by environmental conditions, requirements and frequency of usage.

The items included in the regular inspections are identical to the pre-delivery inspection.

Annual Inspection

An annual machine inspection must be performed once a year and no later than 13 months from the date of the previous annual inspection. Hunan Sinoboom Intelligent Equipment Co., Ltd. recommends this task be performed by a factory-trained service technician, a person recognized by Sinoboom as one who, by qualification, certificate and training, has successfully demonstrated the ability and proficiency to service, repair and maintain the Sinoboom model in question.

Refer to the **Inspection and Preventive Maintenance Schedule** for items requiring annual inspection, and refer to the corresponding section of this manual to perform inspection and maintenance procedures.

Preventive Maintenance

Preventive maintenance procedures shall be performed by qualified Sinoboom technicians. The frequency of the inspection and maintenance must be increased as required by environmental conditions, requirements and frequency of usage.

Refer to the **Inspection and Preventive Maintenance Schedule** for items requiring a PDI. Refer to the corresponding section of this manual to perform inspection and maintenance procedures.

Responsible Persons and Qualifications for Performing Inspection and Maintenance

Table 10-1

Inspection Type	Inspection Frequency	Primary Responsible Persons	Service Qualifications
Pre-operation Inspection	Before starting/restarting work, change of user, after each maintenance activity.	User or operator	Properly trained user or operator
Pre-delivery Inspection (PDI)	Before each sale, lease or rental delivery	Owner, dealer or user	Qualified Sinoboom technician
Regular Inspections	In service for 3 months or 250 hours (whichever comes first) or out of service for more than 3 months	Owner, dealer or user	Qualified Sinoboom technician
Annual Inspection	Once a year and no later than 13 months from the date of the previous annual inspection	Owner, dealer or user	Factory-trained service technician
Preventive Maintenance	At intervals specified in the Inspection and Preventive Maintenance Schedule	Owner, dealer or user	Qualified Sinoboom technician

Inspection and Preventive Maintenance Schedule

Perform inspection and preventive maintenance for the items in the table below at the specified intervals. Maintenance and inspection intervals are calculated based on the months of service or the “accumulated operating hours” (cumulative working time) displayed on the ground controls (whichever comes first).

Inspection intervals are based on the use of the machine under normal operating conditions. The intervals should be shortened accordingly when operating in harsh environmental conditions.

Table 10-2 Inspection and Preventive Maintenance Schedule

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Platform assembly			
Platform	1	1	1
Guardrails and floor	2	2	2
Access gate	1, 2, 3	1, 2, 3	1, 2, 3
Pedal for platform extension	1, 2, 3	1, 2, 3	1, 2, 3

Table 10-2 Inspection and Preventive Maintenance Schedule (continued)

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Platform wear pads (at the connection with scissor arm) and fasteners	1, 2	1, 2	1, 2
Safety belt anchorage point	1, 2, 7	1, 2, 7	1, 2, 7
Scissor arms assembly			
Scissor arms	1, 2	1, 2	1, 2
Safety arm	1, 2, 3	1, 2, 3	1, 2, 3
Bearings	1, 2, 5, 11	1, 2, 5, 11	1, 2, 5, 8, 11
Pivot pins, retaining rings and fasteners	1, 2	1, 2	1, 2
Chassis assembly			
Chassis	2	2	2
Chassis wear pads (at the connection with scissor arm)	1, 2, 5	1, 2, 5	1, 2, 5, 8
Tires	1, 2	1, 2	1, 2
Wheel nuts	1 ⁵⁰	1 ⁵⁰	1 ⁵⁰
Traveling and steering components	1, 2, 5	1, 2, 5	1, 2, 5
Bearings	1, 2, 5, 11	1, 2, 5, 11	1, 2, 5, 11
Chassis door at both sides	1, 2, 3	1, 2, 3	1, 2, 3
Ladder	1, 2, 5	1, 2, 5	1, 2, 5
Drive motor	1, 5, 6	1, 5, 6	1, 5, 6
Brake and brake release device	1, 5, 6	1, 5, 6	1, 5, 6
Electrical system			
Electrical harness, connectors	1, 2	1, 2	1, 2
Battery	1, 2, 6, 9, 11	1, 2, 6, 9, 11	1, 2, 6, 9, 11
Electrolyte	6	6	6
Charging function	3	3	3
Electric actuator	1, 2, 3, 5, 6, 11	1, 2, 3, 5, 6, 11	1, 2, 3, 5, 6, 11
Instruments, gauges, switches, lamps, horn	1, 3	1, 3	1, 3
Functions and controls			
Platform controller	1, 3, 4, 7, 10	1, 3, 4, 7, 10	1, 3, 4, 7, 10
Ground controller	1, 3, 4, 7, 10	1, 3, 4, 7, 10	1, 3, 4, 7, 10
Function control lock, secondary guarding device and brake	1, 3, 10	1, 3, 10	1, 3, 10

Table 10-2 Inspection and Preventive Maintenance Schedule (continued)

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Emergency stop button (ground and platform)	1, 3, 10	1, 3, 10	1, 3, 10
Limit switches and power switch	1, 3, 10	1, 3, 10	1, 3, 10
Overload limit function	1, 3, 10	1, 3, 10	1, 3, 10
Tilt alarm	1, 3, 10	1, 3, 10	1, 3, 10
Pothole protection device	1, 3, 10	1, 3, 10	1, 3, 10
Emergency lowering device	1, 3, 10	1, 3, 10	1, 3, 10
Drive function	1, 3, 10	1, 3, 10	1, 3, 10
Brake function	1, 3, 10	1, 3, 10	1, 3, 10
Other			
Operation Manual in the manuals compartment	10	10	10
All decals/labels complete, clear and secure	10	10	10
Annual inspection date of the machine	/	/	10
No unapproved changes or additions	10	10	10
All safety publications taken into account	10	10	10
General structural components and weldments	2	2	2
All fasteners, pins, protective guards and covers	1, 2	1, 2	1, 2
Greasing and lubricating according to specifications	10	10	10
Functional test of all systems	10	10	10
Paint and appearance	5	5	5
Inspection date stamped on the chassis	/	/	10
Notify Sinoboom of machine ownership (change)	/	/	10

Table 10-2 Inspection and Preventive Maintenance Schedule (continued)

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Note: ¹ Before each sale, lease or shipment delivery; ² In service for 3 months or 250 hours; or out of service for more than 3 months; ³ In service for 6 months or 500 hours; ⁴ Once a year and no later than 13 months from the date of the previous annual machine inspection; ⁵⁰ The first inspection shall be performed once the machine reaches 50 hours in service for the first time. This occurs only once in the service life of the machine. ²⁵⁰ The first inspection shall be performed once the machine reaches 250 hours in service for the first time. This occurs only once in the service life of the machine. NO.1 Before the machine is put into service for the first time			
Inspection activity (numerical codes): 1. Check for correct installation (accurate position, firmly installed, tightened to the specified torque) 2. Visual inspection for damage (cracks, cracked welds, deformation, wear, corrosion, excessive wear, gouges, abrasions and exposed threads) 3. Check for normal function 4. Check for normal return to neutral or "off" position (self-resetting switches return to neutral or "off" position after released) 5. Clean and free of foreign objects 6. Check for correct level, sealing and leaks 7. Labels complete, clear and secure 8. Check for appropriate dimensions/tolerances 9. Fully charged 10. Verify/perform 11. Correctly lubricated			

DECLARATION OF CONFORMITY

Machinery Directive: 2006/42/EC
Electromagnetic Compatibility Directive:
2014/30/EU

Name of manufacturer or supplier

Hunan Sinoboom Intelligent Equipment Co., Ltd.

Full postal address including country of origin

No.128, East Jinzhou Avenue, Ningxiang High-tech Industrial Park, Changsha, Hunan, China

Name of contact person who is authorised to compile the TCF

Sinoboom B.V.

Nikkelstraat 26, NL-2984 AM Ridderkerk, The Netherlands

Description of product

Mobile Elevating Working Platform

Name, type or model, batch or serial number

Name: Mobile Elevating Working Platform

Standards used, including number, title, issue date and other relative documents

EN 60204-1:2018/Safety of machinery - Electrical equipment of machines - General requirements

EN 280-1:2022 / Mobile elevating work platforms - Design calculations - Stability criteria - Construction - Safety - Examinations and tests

Declaration

I declare that as the authorised representative, the above information in relation to the manufacture of this product, is in conformity with the stated standards and other related documents following the provisions of the above Directives and their amendments.

Signature of manufacturer

Always for Better Access Solutions



Hunan Sinoboom Intelligent Equipment Co., Ltd.

No.128, East Jinzhou Avenue, Ningxiang High-tech Industrial Park, Changsha, Hunan, China

☎ 0086-0731-87116222 (Sales) & 0086-0731-87116333 (Service)

✉ sales@sinoboom.com

🏠 www.sinoboom.com

North American Subsidiary

Sinoboom North American LLC

310 Mason Creek Drive
unit #100

Katy, TX 77450, US

Tel: (281) 729-5425

E-mail: info@sinoboom.us

Europe Subsidiary

Sinoboom B.V.

Nikkelstraat 26, NL-2984 AM Ridderkerk,
The Netherlands

Tel: +31 180 225 666

E-mail: info@sinoboom.eu

Korea Subsidiary

Sinoboom Korea Co., Ltd.

95, Docheong-ro, Yeongtong-gu, Suwon-si,
Gyeonggi-do, Republic of Korea

Tel: 010-8310-8026

E-mail: ka1@sinoboom.com

Australia Subsidiary

Sinoboom Intelligent Equipment Pty Ltd.

50/358 Clarendon St, South Melbourne VIC
3205, Australia

E-mail: au@sinoboom.com

Singapore Subsidiary

Star Access Solutions Pte. Ltd.

112 Robinson Road #03-01 Robinson 112
Singapore 068902

Poland Subsidiary

Sinoboom Poland sp. z o.o.

Ul. Bolesława Krzywoustego 74A
61-144 Poznań, Poland