

Operation Manual

Manual No: 515008100002-EN


Manual Version: B

May 2024

Translated version

1323RE/4389RE

1623RE/5389RE



GB CE  AS/NZS EAC 

SINOBOOM



WARNING

Operating, servicing and maintaining this vehicle or equipment can expose you to chemicals including engine exhaust, carbon monoxide, phthalates and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure and avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle or equipment in a well-ventilated area and wear gloves or wash your hands frequently when servicing. For more information, go to: www.P65warnings.ca.gov.

For disposal, please comply with local regulations.

SINOBOOM



星邦智能

星邦

All of the above are registered trademarks of **Hunan Sinoboom
Intelligent Equipment Co., Ltd.**

Contact us:

Website: www.sinoboom.com.cn (China) / www.sinoboom.com (except China)

Sales Tel: 400-601-5828 (China) / 0086-0731-87116222 (except China)

Service Tel: 400-608-1289 (China) / 0086-0731-87116333 (except China)

E-mail: info@sinoboom.com (China) / sales@sinoboom.com (except China)

Address: No.128, East Jinzhou Avenue, Ningxiang High-tech Industrial Park, Changsha,
Hunan, China

Postal code: 410600

Copyright©Hunan Sinoboom Intelligent Equipment Co., Ltd.

Hunan Sinoboom Intelligent Equipment Co., Ltd. retains the right of final interpretation of the manual.

To Users

Thank you for choosing and using the machinery of **Hunan Sinoboom Intelligent Equipment Co., Ltd.**

Use this machine only to transport tools to work locations and for performing tasks on the work platform. Only authorized personnel who have received appropriate MEWP training may operate this machine. Before using the machine, carefully read and fully understand this manual and strictly follow its relevant instructions. Different countries, regions, or governments may have equipment operating regulations that conflict with this manual. The stricter safety operating regulations should be followed. Our company will not be liable for any adverse consequences arising from the failure to operate and use the machine in accordance with this manual or the relevant regulations.

This manual provides necessary safety precautions and operation instructions for users. This manual covers the basic configuration information of one or more models. Please refer to the information applicable to your machine model. Treat this manual as an integral part of the machine and keep it with the machine at all times. This manual may not be copied, distributed, sold, or altered without written permission from Sinoboom.

Due to continuous improvement and upgrading of product design and different product models covered, some charts and textual content in the manual may be not applicable to your machine. Our company reserves the right to revise the contents of this manual due to technological improvements. Changes will be made without prior notice. Contact Sinoboom to obtain the most current version of the manual.

Please go to www.sinoboom.com.cn to download your desired Operation Manual, Maintenance Manual and Parts Manual.

If you have any questions, contact **Hunan Sinoboom Intelligent Equipment Co., Ltd.**

Manual Revision History:

[illegible]

Applicable Models

The manual applies to the following models and serial numbers:

Model	Metric Trade Name	Imperial Trade Name	Serial No.
1323RE	1323RE	4389RE	1500700001 to present
1623RE	1623RE	5389RE	1500800100 to present

Note:

- Check the machine model and serial number on the machine nameplate. The location of the nameplate can be found in the **Decals Diagram** section of the Operation Manual.
- Product model numbers are indicated on the nameplates to distinguish products with different main technical parameters.
- Product trade names (product commercial codes) are used for marketing purposes and machine decals for the differentiation of products with different main technical parameters. Product trade names are categorized as metric and imperial trade names: metric trade names are applicable to regions/countries using the metric system or as specifically requested by customers; imperial trade names are applicable to regions/countries using the imperial system or as specifically requested by customers.

CONTENTS

1	Safety Warning Symbols and Signs	1
2	Important Safety Rules	5
2.1	General	5
2.2	Preparing for Operation	5
2.3	Operation Safety	6
2.4	Towing, Hauling and Lifting Safety	13
2.5	Maintenance Safety	14
3	Responsibilities of Relevant Parties	19
3.1	Owner's (or Lessor's) Responsibilities	19
3.2	Employer's Responsibilities	19
3.3	Trainer's Responsibilities	19
3.4	User's Responsibilities	19
4	Technical Parameters	21
4.1	Machine Specifications	21
4.2	Function Speed	25
5	Pre-operation Inspection	27
5.1	Basic Machine Components	28
5.2	Machine Positions	29
5.3	Pre-start Test	29
5.4	Functional Test	30
6	Controllers and Indicators	33
6.1	Ground Controller (DTC K120 Control System)	33
6.2	Ground Controller (Sinoboom Control System)	35
6.3	Platform Controller (DTC K120 Control System)	37
6.4	Platform Controller (Sinoboom Control System)	39
6.5	Range Extender Controller (if equipped)	41
7	Operation Instructions	45
7.1	General	45
7.2	Gradeability	45
7.3	Activate the Machine	45
7.4	Charging the Battery	46
	Charging via External Power Source	46
	Charging with Range Extender (if equipped with range extender)	48
7.5	Lifting and Lowering the Platform	48
7.6	Traveling	49
7.7	Outrigger Leveling	50
7.8	Extend and Retract Platform	51
7.9	Fold and Unfold Platform Guardrails	51
7.10	Turning Off and Stopping	52
7.11	Transport and Lifting	53
7.12	Storage	56
8	Emergency Procedures ..	57
8.1	Reporting Accidents	57
8.2	Emergency Operation	57
8.3	Emergency Lowering	57
8.4	Emergency Towing	58
9	Decals Diagram	59
10	Maintenance	63
10.1	Lubrication	63

10.2	Oil Specifications	64
10.3	Tire Assembly.....	65
	Check Wheel Nuts	66
	Replacement Requirements	66
	Replace Tire and Wheel Assembly ..	66
10.4	Inspection and Preventative	
	Maintenance Schedule.....	67
	Pre-delivery Inspection (PDI)	67
	Pre-operation Inspection	67
	Regular Inspections	67
	Annual Inspection.....	67
	Preventive Maintenance	67
	Responsible Persons and Qualifi- cations for Performing Inspection and Maintenance	68
	Inspection and Preventive Mainte- nance Schedule	68

1 SAFETY WARNING SYMBOLS AND SIGNS

The safety warning symbols used on the machine and in the manuals have the following meanings:



Safety warning symbol. This symbol is used to alert you to potential hazards. Observe all safety instructions following a symbol to avoid possible injuries.



DANGER

Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.



WARNING

Indicates an imminently hazardous situation that, if not avoided, could result in death or serious injury.

















CAUTION
















Indicates an imminently hazardous situation that, if not avoided, could result in minor or moderate injury.




NOTICE

Indicates information directly or indirectly related to personal safety, machine damage, or property loss.

The safety signs used on the machine and in the manuals have the following meanings:

 Refer to the Maintenance Manual	 Anchor point only for 1 person	 Wind speed	 Chemical burns hazard	 Wedge the wheel
 Refer to the Operation Manual	 Add lubricant	 Crushing hazard – safety shoes required	 Danger of hot, high-pressure fluid spray	 Wind
 Press the directional-control valve	 Repeatedly operate the manual brake release valve	 Release the brake	 Alarm sounding	 Horn
 Noise level	 Burn hazard	 Keep a safe distance from high temperatures	 Pull out-ON Press-OFF	 Collision hazards - never release the brake on slope
 Hydraulic oil filler	 Hydraulic oil level low	 Hydraulic oil level high	 Temperature	 Replace with tires of the same specification
 Only trained maintenance personnel can check the compartment	 Electrocution hazard on platform	 Electrocution hazard on the ground and platform	 Tipping hazard – avoid uneven ground	 Tipping hazard – avoid uneven ground
 Tipping hazard – never use machine in strong, gusty winds	 Tipping hazard – never use machine in strong, gusty winds	 Tipping hazard – never push or pull objects outside the platform	 Tipping hazard – never suspend objects from the platform	 Tipping hazard – never place ladders and scaffolding on the platform

 Tipping hazard – never leave the door open	 Collision hazard – keep head clear of overhead obstacles when raising platform	 Crushing hazard – keep hands clear from overhead obstacles when raising platform	 Collision hazard – keep the platform clear of obstacles below when lowering the platform	 Crushing hazards – keep hands away from scissor arms when lowering the platform
 Fall hazard – never climb on platform guardrails	 Fall hazards – never climb on scissor arms	 Keep a safe distance from power lines	 Battery charging plug	 Platform power plug
 Platform up and down movement	 Indoor use	 Outdoor use	 Emergency lowering handle position	 Maximum platform height
 Only qualified maintenance personnel may perform maintenance work	 Wear protective clothing and safety goggles	 Lateral force	 Electrocution hazard	 Battery explosion hazard
 No smoking or open flames/sparks	 No smoking or open flames/sparks	 Lifting point	 Lashing point	 Tire ground pressure
 Forklift pocket position	 Close the chassis door	 Tool or weight	 Fast/high speed	 Slow/low speed

 Platform load capacity	 Respective load capacity of main platform and platform extension	 Engage the safety strut	 Do not use damaged power cables	
---	---	--	---	--

2 IMPORTANT SAFETY RULES

2.1 GENERAL

This chapter briefly describes the precautions that must be followed for safe and proper operation and maintenance of this machine. To ensure safe use and proper operation of the machine, the operator must perform routine maintenance on the machine in accordance with the Operation Manual and Maintenance Manual. In addition, the machine must be regularly maintained and serviced by a qualified service technician according to the instructions provided in the Maintenance Manual.

Familiarize yourself with the local regulations concerning Mobile Elevated Work Platforms (MEWPs) and related operations. The rules for equipment operation from different countries, regions, or governments may conflict with this manual, so the stricter safety operation rules should be followed. If you have any questions about safety, training, inspection, maintenance, purposes and operation of the machine, please contact Hunan Sinoboom Intelligent Equipment Co., Ltd.

Sinoboom cannot foresee all the potential hazards related to this machine, so all parties involved should place high importance on safety issues.



WARNING

Failure to follow the operating instructions and safety rules in this manual may result in machine damage, property loss, or personal injury.

2.2 PREPARING FOR OPERATION

Operator's Training and Knowledge Requirements

Before operating this machine, read, understand, and comply with all applicable regulations and requirements of employers, local authorities, and the government related to equipment use.

Before operating this machine, you should read and fully understand this manual, undergo professional training based on this Operation Manual, and only operate this machine independently after acquiring the qualification for proficient operation. The training content should include, but not be limited to, the following topics:

- Warnings, operating instructions, and the Operation Manual on the machine.

- Pre-start test
- Factors affecting the stability of the machine
- Common hazards and how to avoid them
- Workplace Inspection
- Functions and related knowledge of all controls, including emergency controls
- Use of personal protective equipment appropriate to the work task, workplace, and environment
- Safe operation
- Transport
- How to prevent unauthorized use

Workplace Inspection

Before and during the operation of the machine, users must pay attention to the hazards and take preventive measures to avoid hazards in the work area. Without the written permission of Hunan Sinoboom Intelligent Equipment Co., Ltd., this machine shall not be used in the following areas or conditions:

- Steep slopes or caves
- Ground with protrusions, obstacles, or debris
- Insecure or slippery surfaces
- Surfaces not sufficient to support the machine (machine weight + load weight)
- Trucks, trailers, rail cars, ships, or other equipment
- Dangerous locations
- Places with overhead electric wires, cranes, or other potential obstacles
- In gusty and/or strong wind conditions, or lightning
- Unauthorized persons
- Other areas where unsafe conditions may occur

Machine Inspection

Make sure to complete all checks in strict accordance with the steps in the **Pre-operation Inspection** section of this manual before operating the machine:

- **Pre-start test**: Ensure that no components are loose/loosening, missing or altered. Components must be securely fixed, without visible damage, leakage, or excessive wear, etc., all parts must be in their original locations and operating position; make sure that all fluid levels, battery level, etc. are appropriate; ensure that maintenance work has been completed

in accordance with the requirements specified in the Maintenance Manual.

- **Decals inspection** : Ensure that no decals and nameplates are missing and/or damaged; decals must be clearly visible.
- **Functional test** : Make sure that all functions of the machine are working properly.



WARNING

It is forbidden to alter or modify the machine without the written permission of Hunan Sinoboom Intelligent Equipment Co., Ltd.

2.3 OPERATION SAFETY

General

WARNING



- This machine shall only be used to transport tools to work locations and for performing tasks on the work platform, and should not be used for other purposes.
- Operators should use personal fall protection equipment (PFPE) while operating the machine. If workplace or other rules require the use of PFPE by persons on the platform, the PFPE should be inspected and used in accordance with the PFPE manufacturer's instructions and applicable government requirements.
- The operator must devote their full attention to their work during the operation of the machine. The use of mobile phones, wireless communication devices, etc. may distract the operator and affect the safe operation of the machine, so the operator should completely stop the machine before using such devices.
- Remove all rings, watches and other accessories before operating the machine, do not wear loose clothing, and do not let long hair hang loosely.
- Individuals who have consumed alcohol or taken medication, who are overly fatigued or mentally distressed, who suffer from health conditions such as heart disease, high blood pressure, epilepsy, etc., individuals with a fear of heights or who feel unwell are prohibited from operating the machine.
- Do not operate a damaged or malfunctioning machine. In case of any failure, stop the machine immediately, label the machine appropriately, and contact the manufacturer or relevant department.
- Never disassemble, modify or retrofit the machine or its parts.
- Never disable any safety devices of the machine.
- Never place objects on the platform guardrails.

WARNING

- Never push the control switch or joystick forcefully through the neutral position directly into the opposite direction. Before pushing the switch to the next function position, move it back to the neutral position and stop, and then move it with slow and uniform force to perform the next function.
- Except in case of emergency, it is forbidden to perform operations from the ground if any person is still on the platform.
- When there are two or more people on the platform, all operation of the machine must be conducted by the operator.
- Always operate the machine in well-ventilated conditions to avoid carbon monoxide or nitrogen oxide poisoning.
- Before leaving the machine, the platform should be completely lowered and all power should be shut off.

Electrocution Hazard

⚠ WARNING





- This machine is not insulated and not equipped with electrocution protection function.
- Do not use this machine during thunderstorms or heavy rain. Should you encounter thunderstorms or heavy rain while operating the machine, immediately lower the platform completely to a safe and stable position, and disconnect all power sources so as to avoid personal injury or machine damage.
- Comply with the national or regional provisions covering minimum safe distance from live conductors. In absence of such provisions, comply with the specifications in the table below to keep a minimum safe distance from power lines, electrical equipment or any live (bare or insulated) components. The minimum safe distance must take into account factors such as machine movement and the swinging or sagging of power lines.
- If an insulating partition rated for the voltage of the power lines is installed, the minimum safe distance can be reduced. Such partitions may not be part of the machine or fixed on the machine. The reduction in the minimum safe distance due to insulating partitions must comply with the relevant national or local regulations.
- Do not use the machine as a ground wire during welding and polishing operations.

Table 2-1 Minimum Safe Distance (continued)

Voltage (Phase to Phase, kV)	Minimum safe distance m (ft)
501-750	10 (32.8)
751-1000	13 (42.7)

⚠ DANGER

Do not operate the machine or transport personnel with the machine within access-restricted areas with live electrical equipment.

Table 2-1 Minimum Safe Distance

Voltage (Phase to Phase, kV)	Minimum safe distance m (ft)
0-50	3 (9.8)
51-220	4 (13.1)
221-500	5 (16.4)

Tripping and Fall Hazards

WARNING



- Before operating the machine, ensure that the platform guardrails are properly installed and that the platform gate is closed and properly secured.
- Operators on the platform must wear the safety belt properly and secure the safety belt to the specified anchorage point with the hook. Each anchorage point should only be used by one person.
- Only enter and exit the platform through the platform gate, never through the scissor, and extra care should be taken. Before entering and exiting the platform, make sure the platform is fully lowered. When entering and exiting the platform, face the platform and maintain three points of contact with the machine, with both hands and one foot or both feet and one hand.
- Both feet must be securely placed on the platform floor at all times. It is forbidden to sit, stand or climb on the platform guardrails.
- Never use ladders, boxes, steps, boards, or similar items on the platform to extend your reach.
- Do not allow oil, sludge or other slippery substances to remain on work shoes and platform floor.
- Keep the platform floor unobstructed.

Tipping Hazard

WARNING



- Before driving the machine onto any ground, bridge, truck or other surface, check if the loading capacity of the surface is sufficient to support the machine (machine weight + platform load). Do not drive the machine on any surfaces or edges that are not capable of fully supporting the machine.
- Operators must familiarize themselves with the ground conditions of the work area before commencing work.
- Do not operate the machine on moving surfaces or vehicles.
- The total weight of personnel, devices and materials on the platform may not exceed the platform's rated load capacity, and all loads must be kept within the designated range of the platform.
- The machine must not be driven on slopes, steps or arched surfaces that exceed the maximum gradeability of the machine.

WARNING



- Do not use the tilt alarm as a level indicator. The tilt alarm on the platform will only sound when the machine is severely tilted.



- When the platform is raised, if the tilt alarm sounds, lower the platform carefully, and do not modify the level switch or limit switch.




- Do not drive the machine on uneven or soft surfaces or slopes that exceed the maximum gradeability of the machine or under other hazardous conditions with the platform raised.



- The platform can only be raised or extended when the machine is on firm, flat ground.



- When the machine is traveling on uneven ground, or on other rough ground with gravel, or near cave openings, steep slopes, etc., be careful and reduce the speed.



- Do not push or pull any objects outside the platform.

- Never push or pull other equipment or objects with the platform or scissor arm.

- Do not place or attach any suspended load on or to any part of the machine.

- Do not place any load outside the perimeter of the platform.

- Using the machine as a hoist or crane is strictly prohibited.

- Never attach the machine or any part of it to any adjacent object.

- Do not operate the machine while the chassis door is opened.

- When one or more tires are off the ground, first evacuate all personnel and then stabilize the machine with cranes, hoists, forklifts, or other suitable equipment.

WARNING

- Without written authorization of the manufacturer, it is forbidden to modify, remove or install any parts, including counterweights, which may affect the safety and stability of the machine.
- Do not replace critical parts that affect the stability of the machine with parts of different weight or specifications. For example, batteries not only provide power, but also serve as a counterweight, and are crucial for maintaining the stability of the machine.

WARNING



- If the machine can be used outdoors, do not operate the machine when the wind speed exceeds 12.5 m/s (28 mph) (including gust). Please refer to the Beaufort wind force scale in the table below. Factors that affect wind speed include: the height of the platform, surrounding terrain, and local weather conditions, such as wind speed at height, which may be much higher than at ground level.
- Wind speeds may change at any time. Always consider the impending weather conditions, the time needed to lower the platform, and methods to monitor the current and potential wind conditions.
- When operating the machine outdoors, do not carry items with a large surface area on the platform, do not cover the surface of the platform or load, and never use additional items to increase the surface area of the platform or load. Adding such additional items will increase the exposure of the machine to the wind. Increasing the windward area will lead to reduced machine stability.

Table 2-2

BEAUFORT SCALE	WIND SPEED		DESCRIP- TION	SURFACE CONDITIONS
	METERS/ SECOND	MILES/ HOUR		
0	0-0.2	0-0.5	Calm	Calm. Smoke rises vertically.
1	0.3-1.5	1-3	Light air	Direction of wind shown by smoke drift.
2	1.6-3.3	4-7	Light breeze	Wind felt on exposed skin. Leaves rustle.
3	3.4-5.4	8-12	Gentle breeze	Leaves and small twigs in constant motion.
4	5.5-7.9	13-18	Moderate breeze	Raises dust and loose paper. Small branches move.
5	8.0-10.7	19-24	Fresh breeze	Small trees sway.
6	10.8-13.8	25-31	Strong breeze	Large branches in motion. Whistling heard in telegraph wires. Umbrella used with difficulty.
7	13.9-17.1	32-38	Near gale	Whole trees in motion. Inconvenience felt when walking against the wind.
8	17.2-20.7	39-46	Gale	Twigs break from trees. Cars veer on the road.
9	20.8-24.4	47-54	Strong gale	Slight structural damage.

**DANGER**

If wind speed exceeds 12.5 m/s (28 mph) after the platform has been raised, the platform should be retracted immediately, all power sources should be disconnected, and the machine should be stopped.

Collision and Crushing Hazards

 WARNING	
	All operators and other personnel in the work area must wear approved safety helmets.
	Keep all parts of the body within the platform guardrails during operation.
	Care should be taken at all times to avoid contact with stationary (built-up structures etc.) objects or moving objects (vehicles, cranes etc.) to prevent obstacles from hitting or interfering with control components or personnel on the platform.
	During operation, make sure to check the clearance and obstacles above, around and below the platform.
	Be aware of the field of vision and potential blind spots when moving or operating the machine. Observers should be put in place in case the field of vision is obstructed.
	- Pay attention to the position of the extending platform while moving the machine. - Make sure there are no persons and/or obstacles below the platform before lowering the platform. - Do not place hands, arms, or other body parts near areas where they may be crushed. - Do not work under the platform or near the scissor arm if the safety arm has not been properly set up. - Ensure that operators of other equipment in the vicinity working at height and on the ground are aware that this MEWP is in operation. - Limit travel speed based on ground conditions, congestion, ground slope, position of personnel, and other factors. - Understand braking distances at all travel speeds. When traveling at high speed reduce the travel speed before stopping. - Do not use the high speed setting when traveling in areas with

 WARNING
limited or enclosed spaces or when reversing. Before releasing the brake, the machine must be placed on a horizontal surface or secured.

2.4 TOWING, HAULING AND LIFTING SAFETY

For towing and dragging procedures, refer to the **Emergency Towing** section of this manual. For transport and lifting procedures, please refer to the **Transport and Lifting** section of this manual.

WARNING



- Except in case of emergency situations, machine malfunction, power loss or loading/unloading, it is strictly prohibited to tow or drag the machine.
- When towing or dragging the machine, comply with local policies and road traffic regulations.
- Before towing, dragging or lifting operations, make sure that the machine is in stowed condition, the machine has no loose or un-fixed parts, and no tools are on the platform.
- Only the lifting points/rigging equipment lashing points on the chassis may be used to tow, haul or lift the machine. Ensure that the machine lifting points/rigging equipment lashing points and their rigging equipment are intact and that the belt or rope to be used has sufficient load strength.
- When towing, hauling or lifting the machine, no persons are allowed on the platform.
- Before loading/unloading the machine, ensure that the transport vehicle is parked on level ground, that the loading surface of the transport vehicle has sufficient capacity/strength to support the machine, and that the slope of the ramp used for driving the machine onto the vehicle does not exceed the maximum gradeability of the machine.
- When loading/unloading the machine, the transport vehicle must be secured to prevent it from moving.
- The wheels should be locked after the machine is loaded to prevent it from moving.
- The machine can only be lifted from the specific position with lifting equipment with sufficient lifting capacity. Care should be taken to prevent the machine from colliding with surrounding objects.

2.5 MAINTENANCE SAFETY

Unsafe Maintenance Hazards

WARNING



- Before performing any adjustment or service operations, power off all control units and ensure that all moving parts are safely secured and cannot move unintentionally.
- Before performing any adjustment or service operations, ensure that the scissor arms are stowed, and do not carry out maintenance with the scissor arms raised. If maintenance must be carried out with the scissor arms raised, take appropriate protective measures to avoid dangerous conditions.
- When lifting or moving heavy parts of the machine, use equipment with sufficient capacity, and never place heavy objects in unstable positions after moving.
- When machine parts are lifted by other equipment, ensure that there are no persons under and/or around the equipment.
- When striking brass rods with a mallet, make sure to wear eye protection.
- If you need to replace parts, use only original parts specified by Sinoboom.
- Do not wash the machine with water. The machine contains electronic components such as solenoid valves and sensors, which may fail or operate erratically after water ingress. If it is necessary to wash with water, turn off the main power switch before proceeding. Only turn the power back on after ensuring the machine is completely dry.
- Make sure the machine is turned off before using flushing equipment (such as a high-pressure water gun) to clean the machine. Do not direct water or steam ejected from the flushing equipment at electrical components, as this may cause short-circuits or electrical shocks.
- After maintenance is completed, thoroughly clean up any spilled

WARNING

hydraulic oil, and avoid allowing it to be spilled on the ground.

- After maintenance is completed, immediately wash off any hydraulic oil that may have come into contact with your skin.
- Waste hydraulic fluids, fuels, coolants and refrigerants must be recycled or disposed as per local regulations.

High Temperature and High Pressure Hazards

WARNING



- While the machine is in operation or after running for a period of time, components may generate high surface temperatures, which can cause burns upon contact. Do not touch any hot parts!
- It is forbidden to repair or tighten hydraulic hoses or seals while the machine is operating or when the oil system is under pressure.
- Before loosening or disassembling hydraulic parts (especially the counterbalance valve on the cylinder), the hydraulic pressure of all hydraulic lines should be released and the hydraulic oil should completely cool down.
- For engine-powered machines, do not attempt to open the radiator cover while it is hot.
- Disassemble the hydraulic components slowly to prevent the hydraulic oil from splashing and causing injuries.
- Never check for hydraulic leaks by hand. Use a piece of cardboard or stiff paper to locate leaks, and wear gloves to protect your hands from spraying hydraulic fluid.
- Do not operate the machine in case of hydraulic or air leaks. Oil or air leakage from the hydraulic system may penetrate and burn the skin.
- Never plug hydraulic leaks by hand. If there is a leak, the pressure of the hydraulic system should be released first, maintenance/repair should be carried out after the hydraulic oil has cooled down.
- If injury occurs due to high temperature and/or high pressure, seek immediate medical attention. If treatment is not carried out immediately, serious complications may result.

Welding and Grinding Operation Hazards

WARNING



- Welding, grinding and polishing operations must follow the appropriate local safety procedures.
- Before performing welding, grinding and polishing operations, turn off the machine's power, and ensure that all wires or cables are connected correctly.
- Do not use the machine as a ground wire during welding and grinding operations.
- Always make sure that all power tools are placed completely within the perimeter of the platform. Do not hang the cords of power tools on the guardrail of the platform or in any work area outside the platform, and do not hang the power tools directly by their cords.

Fire and Explosion Hazards

WARNING



- Do not operate the machine, charge the battery or refuel the machine in places where potentially flammable or explosive gases may be present.
- Refueling and charging should be carried out in a well-ventilated place without flames, sparks, and other hazards that may cause fire or explosion.
- For engine-powered machines, do not refuel the machine while the engine is running.
- Never spray ether or other starting agents into glow-plug-equipped engines (engine-powered machines).
- Never touch the battery terminals or cable clamps with tools that can generate sparks.
- Only approved non-flammable cleaning solutions should be used on the machine.

Battery Hazard

WARNING



- Be sure to read and adhere to the battery manufacturer's recommendations on proper battery use and maintenance procedures.
- Individuals without adequate professional qualification should not repair and maintain the battery system, otherwise this may cause personal injury or damage to the battery system.
- Individuals without adequate professional qualification should not modify parameters, signal lights, etc. during the operation of the battery system, otherwise this may cause personal injury or damage to the battery system.
- Always wear goggles, protective gloves and protective clothing, and remove all rings, watches and other accessories before servicing the battery. Contact with live circuits may result in death or serious injury.
- Before replacing the battery, be sure to select an appropriate number of personnel and suitable lifting methods.
- It is forbidden to modify the battery system without approval to avoid serious accidents.
- When maintaining electrical components, the battery should be disconnected.
- Do not place tools or other metal objects across the two terminals of the battery.
- The battery charger can only be connected to a grounded three-wire AC power outlet. Make sure the charger is working properly before charging. Do not connect the battery directly to a power outlet.
- If the battery becomes hot, deformed, leaks, emits an unusual smell, or produces smoke during use, stop using the battery immediately and report to the relevant maintenance personnel promptly.
- Batteries contain sulfuric acid and can produce explosive

WARNING

mixtures of hydrogen and oxygen. Keep any materials (including cigarette/smoking materials) that can cause sparks or flames away from batteries to prevent explosion.

- Never touch the battery terminals or cable clamps with tools that can generate sparks.
- Never charge the battery in direct sunlight. The battery should be charged in a well-ventilated place.

CAUTION



- Avoid spilling battery acid or allowing it to come into contact with unprotected skin. If battery acid spills, use water mixed with bicarbonate (baking soda) to neutralize the acid. In case of contact with battery acid, rinse the acid off immediately with plenty of water and seek medical attention promptly.
- Always keep the battery upright. If the battery is placed on its side or at an angle, liquid may spill from the battery.
- Discarded batteries can be hazardous, and must not be treated like regular waste. If you need to discard them, please contact a battery recycling company.

NOTICE



- Please use the charger provided by the manufacturer to charge the battery.
- The charging process must be completed in full. Frequent intermittent charging can damage the battery.
- The battery is only suitable for use with the equipment it was provided with at the time of manufacture. Do not use the battery for other purposes.
- Do not reverse the positive and negative terminals of the battery for use.
- Do not short-circuit the positive and negative terminals of the battery system.
- Do not place objects or tools on the battery to prevent short circuiting it.
- Do not strike, throw, step on, or hit the battery with sharp objects.
- Do not immerse the battery in water, acidic, alkaline or salty solutions, and protect the battery from rain.
- The battery should be fully charged immediately after each use of the machine, then the machine power switch should be turned off.

NOTICE

Battery over-discharge (continued use of battery with level of less than 10%) or battery under-voltage caused by long-term non-charging (battery with level of less than 10% not charged for more than three days), resulting in battery capacity attenuation and failure, are not covered by the warranty.

This Page Intentionally Left Blank

3 RESPONSIBILITIES OF RELEVANT PARTIES

3.1 OWNER'S (OR LESSOR'S) RESPONSIBILITIES

- The owner (or lessor) is obliged to help the user understand all the instructions in the manual.
- The owner (or lessor) should provide the latest manuals or replace missing or damaged decals. To obtain the most current machine manuals please contact Sinoboom or its authorized agents.
- The owner (or lessor) should comply with local regulatory requirements related to the use of the machine.

3.2 EMPLOYER'S RESPONSIBILITIES

- The employer must ensure that the operator is properly trained and qualified to operate the machine.
- The employer should ensure that the user is healthy and has good judgment, sense of cooperation and psychological qualities.
- The employer has the responsibility to ensure that signalmen have good visual and auditory judgment, master standard command signals and send clear and accurate signals, and have sufficient experience to identify hazards and inform operators to avoid hazards in time.
- The employer should clarify the corresponding safety responsibilities to each operator and require them to report unsafe factors to the supervisor timely.

3.3 TRAINER'S RESPONSIBILITIES

- The trainer must be accredited by Sinoboom, have comprehensive knowledge training on the machine, and must have the required skills related to machine repair and maintenance.
- The trainer must conduct training in an open area free of hazards until the trainees acquire the ability to safely control and operate the machine.

3.4 USER'S RESPONSIBILITIES

- The user must be properly trained on MEWP, and authorized.
- The user must carefully read and fully understand this manual and the decals on the machine.
- The user must report to the owner (lessor) all anomalies that may cause the machine to work abnormally or have potential dangers, and if possible, correct the abnormal situation promptly while ensuring safety.
- The user must be fully aware of the content and procedures of the respective operation.
- The user must be familiar with and comply with signal instructions and operation requirements in emergency situations.
- The user must be vigilant in observing for any hazardous conditions and promptly report any dangers to other operators and signal personnel. This includes situations such as high-voltage lines, unrelated personnel, and unfavorable ground conditions.
- The user must stop using the equipment if it is not functioning properly or if a hazardous condition arises.

This Page Intentionally Left Blank

4 TECHNICAL PARAMETERS

4.1 MACHINE SPECIFICATIONS

Table 4-1 1323RE Specifications

Item	Metric	Imperial
Product Category		
Power type	Lead-acid battery/lithium battery	
Travel drive type	AC motor	
Outrigger type	H-type	
Dimensions		
Max. platform height	13.1 m	42 ft 11.7 in
Max. working height	15.1 m	49 ft 6.5 in
Maximum horizontal reach (rear platform extension)	1.2 m	3 ft 11.2 in
Maximum horizontal reach (front platform extension)	1.5 m	4 ft 11.1 in
Overall length	4.88 m	16 ft
Overall width	2.28 m	7 ft 5.7 in
Overall height (with guardrails folded)	2.2 m	7 ft 2.6 in
Overall height (with guardrails not folded)	2.96 m	9 ft 8.5 in
Wheelbase	2.84 m	9 ft 3.8 in
Track width	1.95 m	6 ft 4.7 in
Ground clearance	0.36 m	1 ft 2.2 in
Platform dimensions (L×W×H) -6.5 m platform	3.96 m×1.82 m×1.1 m	13 ft×6 ft×3 ft 7 in
Platform dimensions (L×W×H) -7.4 m platform	4.84 m×1.82 m×1.1 m	15 ft 10.6 in×6 ft×3 ft 7 in
Performance		
Rated platform capacity	680 kg	1499 lb
Rated platform extension capacity	227 kg	500 lb
Maximum number of occupants	7 persons	
Travel speed (stowed)	0 – 5.3 km/h	0 – 3.3 mph
Travel speed (raised)	0 – 1.1 km/h	0 – 0.68 mph
Platform lifting time (unloaded)	50 – 60 s	
Platform lowering time (unloaded)	34 – 44 s	

Table 4-1 1323RE Specifications (continued)

Item	Metric	Imperial
Gradeability	40%	
Maximum allowable tilt angle (front-rear, outrigger retracted/extended)	3°/0.5°	
Maximum allowable tilt angle (left-right, outriggers retracted/extended)	2°/0.5°	
Maximum outrigger leveling angle (front-rear/left-right)	7°/12°	
Turning radius (inside/outside)	2.2 m/5.3 m	7 ft 2.6 in/17 ft 4.7 in
Tire size (diameter×width/type)	33×12-20/solid	315/55D20/foam-filled
Maximum operating noise level	72dB (without range extender) 86dB (with range extender)	
IP rating	IP 54	
Maximum total vibration on the platform	2.5 m/s ²	
Maximum whole body vibration value (WBV)	0.5 m/s ²	
Power		
Drive x steer	4 WD×2 WS	
Hydraulic tank volume	110 L	24 gal (UK)/29 gal (US)
Hydraulic system pressure	24 MPa	3481 psi
Battery specifications (voltage, capacity, rate of discharge)	Lead-acid battery – 48 V, 480 Ah, 5 hr Lithium battery – 51.2 V, 500 Ah, 0.2 C	
System voltage	48 VDC	
Control voltage	12 VDC	
Charger (input voltage/output current)	100 – 240 V AC/60 A	
Lift motor (voltage/power)	48 V DC/8 kW	
Drive motor (voltage/power)	29 V AC/1.5 kW	
Weight		
Gross weight (without range extended charging package)	7970 kg	17571 lb
Gross weight (with range extended charging package)	8360 kg	18431 lb
Ground bearing data		
Maximum tire load	3900 kg	8598 lb
Tire ground pressure	720 kPa	104 psi
Maximum outrigger ground load	3200 kg	7055 lb
Outrigger ground pressure	630 kPa	91 psi

Table 4-1 1323RE Specifications (continued)

Item	Metric	Imperial
Environment		
Maximum allowable lateral force	400 N	90 lbf
Maximum allowable wind speed (indoor/outdoor)	0/12.5 m/s	0/28 mph
Maximum allowable altitude	1000 m	3280.8 ft
Allowable ambient temperature range (lead-acid battery)	-10°C – 40°C	14°F – 104°F
Allowable ambient temperature range (lithium battery)	-20°C – 40°C	-4°F – 104°F
Maximum allowable relative humidity	90 %	
Storage environment	Store at -20° C to 50° C (-4° F to 122° F) in a well-ventilated environment with 90 % relative humidity (max.) (20° C [68° F]), protected from rain, sun, corrosive gas, flammable or explosive materials.	

Table 4-2 1623RE Specifications

Item	Metric	Imperial
Product Category		
Power type	Lead-acid battery/lithium battery	
Travel drive type	AC motor	
Outrigger type	H-type	
Dimensions		
Max. platform height	16.2 m	53 ft 1.8 in
Max. working height	18.2 m	59 ft 8.5 in
Maximum horizontal reach (rear platform extension)	1.2 m	3 ft 11.2 in
Maximum horizontal reach (front platform extension)	1.5 m	4 ft 11.1 in
Overall length	4.88 m	16 ft
Overall width	2.28 m	7 ft 5.7 in
Overall height (with guardrails folded)	2.42 m	7 ft 11.3 in
Overall height (with guardrails not folded)	3.18 m	10 ft 5.2 in
Wheelbase	2.84 m	9 ft 3.8 in
Track width	1.95 m	6 ft 4.7 in
Ground clearance	0.36 m	1 ft 2.2 in
Platform dimensions (L×W×H) -6.5 m platform	3.96 m×1.82 m×1.1 m	13 ft×6 ft×3 ft 7 in
Platform dimensions (L×W×H)	4.84 m×1.82 m×1.1 m	15 ft 10.6 in×6 ft×3 ft 7 in

Table 4-2 1623RE Specifications (continued)

Item	Metric	Imperial
-7.4 m platform		
Performance		
Rated platform capacity	680 kg	1499 lb
Rated platform extension capacity	227 kg	500 lb
Maximum number of occupants	4 persons	
Travel speed (stowed)	0 – 5.3 km/h	0 – 3.3 mph
Travel speed (raised)	0 – 1.1 km/h	0 – 0.68 mph
Platform lifting time (unloaded)	70 – 90 s	
Platform lowering time (unloaded)	45 – 55 s	
Gradeability	40%	
Maximum allowable tilt angle (front-rear, outrigger retracted/extended)	3°/0.5°	
Maximum allowable tilt angle (left-right, outriggers retracted/extended)	2°/0.5°	
Maximum outrigger leveling angle (front-rear/left-right)	7°/12°	
Turning radius (inside/outside)	2.2 m/5.3 m	7 ft 2.6 in/17 ft 4.7 in
Tire size (diameter×width/type)	33×12-20/solid	315/55D20/foam-filled
Maximum operating noise level	72dB (without range extender) 86dB (with range extender)	
IP rating	IP 54	
Maximum total vibration on the platform	2.5 m/s²	
Maximum whole body vibration value (WBV)	0.5 m/s²	
Power		
Drive x steer	4 WD×2 WS	
Hydraulic tank volume	110 L	24 gal (UK)/29 gal (US)
Hydraulic system pressure	24 MPa	3481 psi
Battery specifications (voltage, capacity, rate of discharge)	Lead-acid battery – 48 V, 480 Ah, 5 hr Lithium battery – 51.2 V, 500 Ah, 0.2 C	
System voltage	48 VDC	
Control voltage	12 VDC	
Charger (input voltage/output current)	100 – 240 V AC/60 A	
Lift motor (voltage/power)	48 V DC/8 kW	
Drive motor (voltage/power)	29 V AC/1.5 kW	

Table 4-2 1623RE Specifications (continued)

Item	Metric	Imperial
Weight		
Gross weight (without range extended charging package)	8800 kg	19400 lb
Gross weight (with range extended charging package)	9190 kg	20260 lb
Ground bearing data		
Maximum tire load	3900 kg	8598 lb
Tire ground pressure	720 kPa	104 psi
Maximum outrigger ground load	3200 kg	7055 lb
Outrigger ground pressure	630 kPa	91 psi
Environment		
Maximum allowable lateral force	400 N	90 lbf
Maximum allowable wind speed (indoor/outdoor)	0/12.5 m/s	0/28 mph
Maximum allowable altitude	1000 m	3280.8 ft
Allowable ambient temperature range (lead-acid battery)	-10°C – 40°C	14°F – 104°F
Allowable ambient temperature range (lithium battery)	-20°C – 40°C	-4°F – 104°F
Maximum allowable relative humidity	90 %	
Storage environment	Store at -20° C to 50° C (-4° F to 122° F) in a well-ventilated environment with 90 % relative humidity (max.) (20° C [68° F]), protected from rain, sun, corrosive gas, flammable or explosive materials.	

Note:

- a) The platform height plus the operator height (taken as 2 m/6 ft 7 in) equals the working height.
- b) In different areas, hydraulic oil, engine oil, coolant, fuel and lubricant should be added in accordance with the environmental temperature.
- c) In cold weather, auxiliary devices are needed to start the machine.
- d) The ground bearing data is approximate, without considering different options, thus it is applicable only when taking an adequate safety factor into account.
- e) Rated platform load capacity refers to the maximum allowable load on the platform, including the weight of persons, materials, tools, accessories and other objects.
- f) The hydraulic tank capacity is the maximum volume of the tank.

4.2 FUNCTION SPEED

Table 4-3

Item	Parameter
Raise the platform - 1323RE	50 – 60 s
Raise the platform - 1623RE	70 – 90 s

Table 4-3 (continued)

Item	Parameter
Lower the platform - 1323RE	34 – 44 s
Lower the platform - 1623RE	45 – 55 s
Travel in high gear – stowed	25 – 30 s

Table 4-3 (continued)

Item	Parameter
Travel in low gear – stowed	60 – 72 s
Travel – operating	60 – 72 s
Braking distance	S≤1.2 m (3 ft 11 in)

- a) The function speed depends on the start and end point of the movement rather than the controls/ switches.
- b) The drive speed test results will vary with tires of different specifications.
- c) All speed tests should be conducted from the platform controller. Test results will differ if tested from the ground controller.
- d) All tests should be conducted with the hydraulic oil temperature higher than 30 - 40 °C (86 - 104 °F). If the hydraulic oil temperature is too low the test results will be affected.

Test requirements:

Raise the platform: After all outriggers have been extended to the ground and leveled, with the platform unloaded, raise the platform (with the scissor arms from fully retracted position to fully raised position). Perform this maneuver for two times.

Lower the platform: After all outriggers have been extended to the ground and leveled, with the platform unloaded, lower the platform (with the scissor arms from fully raised position to fully retracted position). Perform this maneuver for two times.

Travel in high gear – stowed: With the machine stowed on a level surface, switch to high gear, and push the travel joystick to the maximum travel distance to drive the machine forward and reverse for 40 m (131.2 ft) respectively for two times.

Travel in low gear - stowed: With the machine stowed on a level surface, switch to low gear, and push the travel joystick to the maximum travel distance to drive the machine forward and reverse for 20 m (65.6 ft) respectively for two times.

Travel - operating: With the machine in operating position on a level surface, push the travel joystick to the maximum forward position to drive the machine forward and reverse for 20 m (65.6 ft) respectively for two times.

Braking distance : As described in the “travel in high gear - stowed” test requirements, once the machine reaches the maximum drive speed, immediately release the control handle (starting timing) until the machine stops. Perform this maneuver for two times.

5 PRE-OPERATION INSPECTION

A pre-operation inspection must be performed before each operation, before resuming operations, and before changing operators, as well as after each repair. Please carefully check each item according to the content of this section.

5.1 BASIC MACHINE COMPONENTS




Fig. 1

Table 5-1

1. Platform controller	2. Harness anchorage point	3. Front platform extension
4. Main platform	5. Rear platform extension	6. Scissor arms assembly
7. Upper lift cylinder (only 1623RE)	8. Lower lift cylinder	9. Safety strut
10. Front wheel (steering wheel)	11. Drive reducer	12. Power-off handle
13. Power battery	14. Ladder	15. Ground controller
16. Rear wheel (non-steering wheel)	17. Outrigger	18. Hydraulic tank
19. Power-off switch	20. Fuel tank (if equipped with range extender)	21. Range extender (if equipped)
22. Starting battery		

5.2 MACHINE POSITIONS

The machine positions/states covered in this manual are stowed position, transport position, operating position, and non-operating position. Each position is described in detail below:

- **Stowed position:** the scissor arms are fully retracted.
- **Transport position:** the scissor arms, the platform extension and the outriggers are fully retracted.
- **Operating position (raised):** the scissor arms are elevated until disengaged from the down limit switch.
- **Non-operating position:** the scissor arms are not disengaged from the down limit switch.

Note: when the scissor arms are disengaged from the down limit switch, the platform height (from the ground to the platform floor) shall be: 3±0.3 m (9 ft 10 in±10 in).

5.3 PRE-START TEST

WARNING

If any damage, malfunction, or unauthorized modifications differing from the factory state are found with the machine, it should be immediately tagged and shut down. Report the fault to the relevant maintenance personnel and do not operate the machine until safe operation can be guaranteed.

The pre-start test shall include the following:

1. Cleanliness – inspect all surfaces of the machine for leaks (hydraulic oil, fuel, engine oil or battery electrolyte, etc.) or foreign objects.

2. Structure – check whether there are any abnormalities in the equipment structure, such as dents, damage, cracks in welds or structural components, severe rust, severe corrosion, etc.
3. Operation Manual and Maintenance Manual – ensure that the Operation Manual and Maintenance Manual are intact, easy to read, and stored in the manuals storage box on the platform.
4. Decals and nameplate – ensure that labels and the nameplate are in place, intact, accurately located and visible.

WARNING

Do not operate the machine if any label or nameplate is missing or worn.

5. Maintenance – ensure that maintenance has been completed on the machine in accordance with the maintenance inspection requirements specified in the Maintenance Manual.
6. Battery – charge the battery as required. The electrolyte level, if adjustable, must be kept at an appropriate height.
7. Fuel level (if equipped with an engine) – add fuel as needed.
8. Engine oil level (if equipped with an engine) – make sure the oil level is between the “FULL” and “ADD” level of the oil dipstick and that the filler cap is tightened.
9. Coolant level (if equipped with a water-cooled engine) – add coolant as needed.
10. Hydraulic oil – check the hydraulic oil level. Add a suitable amount of hydraulic oil as needed.
11. Options/accessories – if the machine is equipped with any options/accessories, consult the supplemental manuals for options/accessories for inspection, operation and maintenance instructions.

12. Machine components – in addition to checking other stated items, check the following components to ensure that they are correctly installed and firmly attached without loose, missing or altered parts and visible damage, leakage or excessive wear, etc., and that all components are in their original positions and normal operating position.

- 1) Platform assembly and gate – the platform extension shall extend and retract normally and be secured firmly; all wire rope safety pins (if equipped) for supporting the platform shall be installed properly. Ensure that the rope anchorage points are safe and reliable with only one person per anchorage point; make sure the latches and hinges are in normal working states, that the platform gate opens and closes properly, is not bent or damaged, and that the surrounding area is free of obstacles. The gate should remain closed at all times, except for entering/exiting the platform and loading/unloading materials.
- 2) Ground and platform controllers, range extender controller (if equipped) – ensure that all control switches are off, joysticks are in neutral position and can return to neutral position normally once activated and released (self-resetting switches can return to neutral position normally after release), and that all control markings are visible;
- 3) Scissor assembly;
- 4) Engine, fuel tank and related components (if equipped with an engine);
- 5) Tire and wheel assembly – ensure that the tire and wheel assembly is firmly secured and wheel nuts are not loose or missing; check for worn tread, cuts, breakage or other abnormalities;
- 6) Drive system components (electric motor, reducer, etc.);
- 7) Steering linkage and steering connection plate;
- 8) Outriggers (if equipped);
- 9) Hydraulic cylinders, manifolds, pumps, oil tank, hoses, pipe fittings and other hydraulic parts;
- 10) Electrical parts such as limit switches and wire harnesses.

NOTICE

Make sure to check the platform floor area, as inspection of this area may uncover conditions that could cause personal injury or machine damage.

5.4 FUNCTIONAL TEST

Before performing a functional test:

- Choose a firm, flat and level test area.
- Make sure the test area is free from obstructions.



WARNING

If any switch/handle returns to the neutral position but the corresponding movement does not stop, push in the emergency stop button to stop the machine.

Follow these steps to perform a functional test:

1. With no load on the working platform switch the ground/platform control selector switch of the ground controller to the ground control position, pull out the emergency stop button on the ground controller, and perform the following checks from the ground controller:
 - 1) Make sure that the screen is turned on and shows no error message during the entire functional test.
 - 2) Make sure that when the emergency stop button is pressed, the controller is powered off, the machine cannot be started and no functions operate.
 - 3) Activate the range extender – the range extender can charge the battery normally.
 - 4) Activate any action switch without activating the enable switch, and the corresponding action cannot operate.
 - 5) Activate the enable switch and any action switch at the same time, and the corresponding action shall operate normally. Release the switch/handle after one action is performed – the corresponding action should be stopped reliably and safely.
2. Switch the ground/platform control selector switch of the ground controller to the platform control position, pull out the emergency stop button on the ground controller and platform controller, and perform the following checks from the platform controller:
 - 1) Make sure that when the emergency stop button at the platform controller is pressed, the platform controller is powered off, and no function can be activated from the platform controller.
 - 2) Make sure that the horn sounds properly when the horn button is pressed.
 - 3) Activate the range extender – the range extender can charge the battery normally.
 - 4) Activate any action switch/handle without activating the enable switch – the corresponding function cannot be activated.

- 5) Activate the enable switch and any action switch/handle at the same time, and the corresponding action shall operate normally. Move the switch/handle to the neutral position after an action is performed – the corresponding action should stop reliably and safely.

Note: When the travel joystick is released, the brake must be able to hold the machine on any slope within the maximum gradeability reliably without sliding.

- 6) In platform lift and lower mode, the joystick controls the platform lifting and lowering functions, while the travel and steer functions shall be disabled.
- 7) In drive and steer mode, the joystick controls travel and steer functions, while the platform lifting and lowering functions shall be disabled.
- 8) With the outrigger leveling switch activated, the joystick controls travel and steer functions, while the travel and steer functions shall be disabled.
- 9) With the machine in non-operating position, the outrigger leveling switch not activated and the low travel speed mode not activated, activate

the drive and steer mode and push the joystick – the machine shall travel at high speed. Pushing the joystick to the full drive position will bring the machine to travel at the maximum travel speed.

- 10) With the machine in non-operating position, the outrigger leveling switch not activated and the turtle speed button pressed, activate the drive and steer mode and push the joystick – the machine shall travel at low speed. Push the joystick to the full drive position – the machine shall travel at the maximum speed in low speed mode (for platform controller with DTC control system).
- 11) With the machine in non-operating position, the outrigger leveling switch not activated and the creep button pressed, activate the drive and steer mode and push the joystick – the machine shall travel at low speed. Push the joystick to the full drive position – the machine shall travel at the maximum speed in low speed mode (for platform controller with Sinoboom control system).
- 12) With the machine in operating position, the travel speed of the machine will be reduced to the speed for the raised position automatically.

This Page Intentionally Left Blank

6 CONTROLLERS AND INDICATORS

This chapter provides a brief introduction of switches, handles and screens at the ground controller and platform controller. Refer to the **Operation Instructions** section for a detailed description.

6.1 GROUND CONTROLLER (DTC K120 CONTROL SYSTEM)

NOTICE

The manufacturer cannot directly control the application and operation of the machine. Users and operators are responsible for complying with the applicable safety specifications.




Fig. 1

Table 6-1

No.	Name	Description
1	Buzzer	/
2	Emergency stop button	When pulled to the "ON" position the machine can be started normally; pushing the button to the "OFF" position will deactivate the controller, the machine cannot be started and no functions can be activated.

Table 6-1 (continued)

No.	Name	Description
3	Ground control position	/
4	Neutral/OFF position	/
5	Platform control position	/
6	Key switch (ground/platform control selector switch)	Set the switch to neutral position: the machine will be powered off. Turn the switch to "platform control position": all functions will be operative only at the platform controller; the ground controller will not work. Turn the switch to "ground control position", and all functions will be operative only at the ground controller while the platform controller will not work.
7	1) Platform Up key 2) Up arrow key	1) Controls platform lifting function together with the enable key; 2) Scroll up the ECU menu screen
8	Emergency lowering combined keys	Pressing the combined keys could lower the platform.
9	1) Enable key 2) Enter key	1) Press and hold the key - platform lifting and lowering functions will be enabled to operate. 2) Enter the next interface of the ECU menu screen.
10	1) Platform Down key 2) Down arrow key	1) Controls platform lowering function together with the enable key; 2) Scroll down the ECU menu screen
11	Not used	/
12	Range extender manual start switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the range extender will be activated to charge the battery; Press this switch again - the range extender will stop charging.
13	Charging mode selector switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the switch indicator light will illuminate and the machine will change to automatic charging mode with the symbol "A" of automatic charging mode displayed on the screen; Press this switch again - the switch indicator light will go out and the machine will change to manual charging mode with the symbol "M" of automatic charging mode displayed on the screen.
14	Overload indicator	This indicator illuminates to indicate that the load on the platform exceeds its rated load.
15	Ground controller display screen	ECU menu selection/setting interface

6.2 GROUND CONTROLLER (SINOBOOM CONTROL SYSTEM)




Fig. 2

Table 6-2

No.	Name	Description
1	Buzzer	/
2	Emergency stop button	When pulled to the “ON” position the machine can be started normally; pushing the button to the “OFF” position will deactivate the controller, the machine cannot be started and no functions can be activated.
3	Ground control position	/
4	Neutral/OFF position	/
5	Platform control position	/
6	Key switch (ground/platform control selector switch)	Set the switch to neutral position: the machine will be powered off. Turn the switch to “platform control position”: all functions will be operative only at the platform controller; the ground controller will not work. Turn the switch to “ground control position”, and all functions will be operative only at the ground controller while the platform controller will not work.

Table 6-2 (continued)

No.	Name	Description
7	Platform Up key	Control platform up function
8	Emergency lowering combined keys	Pressing the combined keys could lower the platform.
9	Platform Down key	Control platform down function
10	Enable key	Press and hold the key - platform lifting and lowering functions will be enabled to operate.
11	Not used	/
12	Charging mode selector switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the switch indicator light will illuminate and the machine will change to automatic charging mode with the symbol "A" of automatic charging mode displayed on the screen; Press this switch again - the switch indicator light will go out and the machine will change to manual charging mode with the symbol "M" of automatic charging mode displayed on the screen.
13	Not used	/
14	Range extender manual start switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the range extender will be activated to charge the battery; Press this switch again - the range extender will stop charging.
15	Enter key	Enter the next interface of the ground display screen
16	Down arrow key	Scroll down the ground display screen
17	Return key	Go to the previous interface of the ground display screen
18	Up arrow key	Scroll up the ground display screen
19	Ground controller display screen	ECU menu selection/setting interface

6.3 PLATFORM CONTROLLER (DTC K120 CONTROL SYSTEM)




Fig. 3

Table 6-3

No.	Name	Description
1	Enable switch	Move and hold the switch – all functions will be enabled to operate.
2	Left turn thumb button	Press the button to steer the machine to the left.
3	Right turn thumb button	Press the button to steer the machine to the right.
4	Joystick	In platform lift and lower mode, pushing this joystick forward/back will raise/lower the platform; In drive and steer mode, pushing this joystick forward/back will drive forward/back; In outrigger leveling mode, pushing this joystick forward/back will retract/extend the outriggers.
5	Drive and steer function enable switch	Pressing this switch will cause the switch indicator to illuminate, and drive and steer mode will be activated.
6	Platform lift and lower function enable switch	Pressing this switch will cause the switch indicator to illuminate, and platform lift and lower mode will be activated.
7	Turtle speed button	Press the button, and the button light will illuminate and the low travel speed mode will be enabled.
8	Range extender manual start switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol “M” of manual charging mode will be displayed on the display screen;

Table 6-3 (continued)

No.	Name	Description
		Press this switch - the range extender will be activated to charge the battery; Press this switch again - the range extender will stop charging.
9	Platform display	Display machine fault codes.
10	Not used	/
11	RF outrigger leveling enable switch	Pressing this switch will enable the right front outrigger leveling mode.
12	RR outrigger leveling enable switch	Pressing this switch will enable the right rear outrigger leveling mode.
13	Outrigger auto leveling enable switch	Pressing this switch will enable the automatic outrigger leveling mode.
14	LR outrigger leveling enable switch	Pressing this switch will enable the left rear outrigger leveling mode.
15	LF outrigger leveling enable switch	Pressing this switch will enable the left front outrigger leveling mode.
16	Work light switch (if equipped)	Pressing this switch will cause the switch indicator to illuminate, and work light will be turned on.
17	Horn button	Press the button to sound the horn.
18	Charging mode selector switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the switch indicator light will illuminate and the machine will change to automatic charging mode with the symbol "A" of automatic charging mode displayed on the screen; Press this switch again - the switch indicator light will go out and the machine will change to manual charging mode with the symbol "M" of automatic charging mode displayed on the screen.
19	Not used	/
20	Emergency stop button	Pull out the button to the ON position – the platform controller will function normally; press the button to the OFF position, the platform controller will be powered off and no function can be activated from the platform controller

6.4 PLATFORM CONTROLLER (SINOBOOM CONTROL SYSTEM)




Fig. 4

Table 6-4

No.	Name	Description
1	Enable switch	Move and hold the switch – all functions will be enabled to operate.
2	Left turn thumb button	Press the button to steer the machine to the left.
3	Right turn thumb button	Press the button to steer the machine to the right.
4	Joystick	In platform lift and lower mode, pushing this joystick forward/back will raise/lower the platform; In drive and steer mode, pushing this joystick forward/back will drive forward/back; In outrigger leveling mode, pushing this joystick forward/back will retract/extend the outriggers.
5	Not used	/
6	Not used	/
7	Platform display	Display machine fault codes.

Table 6-4 (continued)

No.	Name	Description
8	Range extender manual start switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the range extender will be activated to charge the battery; Press this switch again - the range extender will stop charging.
9	Drive and steer function enable switch	Pressing this switch will cause the switch indicator to illuminate, and drive and steer mode will be activated.
10	Creep mode enable switch	Pressing this switch will cause the switch indicator to illuminate, and creep mode will be activated.
11	Horn button	Press the button to sound the horn.
12	Charging mode selector switch (if equipped with range extender)	After the machine is powered on, the default charging mode is manual mode, and the symbol "M" of manual charging mode will be displayed on the display screen; Press this switch - the switch indicator light will illuminate and the machine will change to automatic charging mode with the battery level and the symbol "A" of automatic charging mode displayed alternatively on the screen; Press this switch again - the switch indicator light will go out and the machine will change to manual charging mode with the symbol "M" of automatic charging mode displayed on the screen.
13	Platform lift and lower function enable switch	Pressing this switch will cause the switch indicator to illuminate, and platform lift and lower mode will be activated.
14	RF outrigger leveling enable switch	Pressing this switch will enable the right front outrigger leveling mode.
15	RR outrigger leveling enable switch	Pressing this switch will enable the right rear outrigger leveling mode.
16	Outrigger auto leveling enable switch	Pressing this switch will enable the automatic outrigger leveling mode.
17	LR outrigger leveling enable switch	Pressing this switch will enable the left rear outrigger leveling mode.
18	LF outrigger leveling enable switch	Pressing this switch will enable the left front outrigger leveling mode.
19	Not used	/
20	Not used	/
21	Not used	/
22	Emergency stop button	Pull out the button to the ON position – the platform controller will function normally; press the button to the OFF position, the platform controller will be powered off and no function can be activated from the platform controller

6.5 RANGE EXTENDER CONTROLLER (IF EQUIPPED)




Fig. 5 Controller

Table 6-5 Controller Description

No.	Name	Description
1	Alarm indicator	Indicates alarm or fault information of range extender controller (on the right side of the icon)
2	Status indicator	Indicates the operating status of range extender controller (on the right side of the icon)
3	Manual mode indicator light	This indicator light illuminates steadily to indicate that the range extender controller is in manual start mode.
4	Auto mode indicator light	This indicator light illuminates steadily to indicate that the range extender controller is in automatic start mode.
5	Stop mode indicator light	This indicator light illuminates steadily to indicate that the range extender controller is in stop mode.
6	1) Stop key 2) Reset key	1) Pressing this key will bring the range extender controller to stop; 2) When an engine fault alarm is triggered, press and hold this key - the alarm will be cleared.
7	Auto key	Press this key - the range extender controller will enter automatic start mode, and the auto mode indicator light will illuminate.
8	Manual key	Press this key - the range extender controller will enter manual start mode, and the manual mode indicator light will illuminate.
9	Background light On/Off key	Pressing this key to turn on or off the background light of the screen.
10	Start key	Press this key - the engine will be started.

Table 6-5 Controller Description (continued)

No.	Name	Description
11	1) Down arrow key 2) Configuration (-) key	1) Pressing this key to scroll down the menu screen 2) Pressing this key to decrease the configuration parameter value.
12	1) Menu key 2) Configuration confirm key	1) Pressing this key to enter the controller setting screen 2) Pressing this key to confirm or save the selected or modified configuration parameter.
13	1) Up arrow key 2) Configuration (+) key	1) Pressing this key to scroll up the menu screen 2) Pressing this key to increase the configuration parameter value.
14	Display screen	Displays status, alarms and other service information of range extender.
15	Emergency stop button	When pulled to the “ON” position the range extender can be started normally; Pushing the button to the “OFF” position will deactivate the range extender.

Note:

- When the range extender is in standby status, the status indicator lights #3, #4 and #5 go off.
- When the range extender is starting or stopping, the status indicator lights #3, #4 and #5 flash once per second.
- When the range extender is operating normally, the status indicator lights #3, #4 and #5 illuminate steadily.



Fig. 6 Home Screen

Table 6-6 Description of Home Screen

No.	Name	Description
1	Not used	\
2	Output voltage	Indicates the current output voltage of range extender controller
3	Generator frequency	Indicates the current frequency of generator
4	Operating status	Indicates the current operating status of range extender controller
5	Not used	\
6	Not used	\

Table 6-6 Description of Home Screen (continued)

No.	Name	Description
7	Not used	\
8	Battery voltage	Indicates the current voltage of machine's starting battery

This Page Intentionally Left Blank

7 OPERATION INSTRUCTIONS

7.1 GENERAL

This mobile elevating work platform is used to transport tools to work locations and for performing tasks on the work platform. This machine has two control positions: ground control position and platform control position.

WARNING

- Except in case of emergency, it is forbidden to perform operations from the ground if any person is still on the platform.
- If any switch/handle returns to the neutral position but the corresponding movement does not stop, push in the emergency stop button to stop the machine.
- The replacement joystick of the platform controller must be of the same brand as the original one, otherwise the machine functions may be impeded or accidents may occur.


7.2 GRADEABILITY

Gradeability refers to the maximum allowable slope angle the machine can achieve on firm ground with sufficient traction, the platform in stowed position and occupied by only one person. Gradeability will decrease when the load on the platform increases.

WARNING


Do not drive the machine on slopes exceeding the machine's maximum gradeability.

The gradeability includes uphill/downhill as well as lateral slope capability. Uphill/downhill gradeability of this machine:



Uphill/downhill: 40%/22 °

Lateral slope limit:



Lateral slope: 25 %/14°

7.3 ACTIVATE THE MACHINE

NOTICE

Before activating the machine, make sure that:

- The power switch is turned on.
- The lithium battery, if acting as the power source, is activated (refer to **Activating Lithium Battery**).

Note: The first start must always be done from the ground control position.

Start machine from the ground

1. Turn the ground/platform control selector switch at the ground control position to the Ground control position.
2. Pull out the emergency stop button at the ground control position to the ON position.
3. The turntable screen will be turned on and should show no error message. All functions will be operative only at the ground control position; the platform control position will not work.

Start machine from the platform

1. Turn the ground/platform control selector switch at the ground control position to the platform control position.
2. Pull out the emergency stop button at the ground control position to the ON position.
3. Pull out the emergency stop button at the platform control position to the ON position.



WARNING

Before pulling out the emergency stop button at the platform controller, ensure the joystick is in the neutral position; if not, do not operate the machine.

- The platform screen will be turned on and should show no error message. All functions will be operative only at the platform control position; the ground control position will not work.

ACTIVATE LITHIUM BATTERY

If your machine is equipped with a lithium battery, it may be needed to activate the battery when it has entered sleep mode.

The lithium battery will go into sleep mode under the following conditions:

- When the machine has not been used for 72 hours (the discharge current has been lower than 10 A for 72 hours).
- During BMS operation, if the system detects that the HV3 signal has lost for more than 5s, the 3 minute timer will be triggered; and if the HV3 signal is not detected within the 3 minutes, the lithium battery will enter the sleep mode;
- When the state of charge (SOC) of lithium battery is between 7% and 15%, after the battery has operated for 5 minutes;
- When the SOC is less than 7%.

To use the machine again, push the start switch of the lithium battery, or charge the battery.

NOTICE

- When the SOC is between 7% and 15%, the lithium battery can be activated by pushing the start switch for several times until the SOC is lower than 7%;
- When the SOC is less than 7%, the lithium battery cannot be activated by pushing the start switch, and it must be connected to an external charger to get charged.

7.4 CHARGING THE BATTERY

Charging via External Power Source

There are three types of batteries that may be used in this machine: Lead acid battery, maintenance-free lead acid battery, and lithium battery. The latter two types do not require maintenance.

The battery level must be checked before each operation.

When the battery level is too low, the low battery alarm will be displayed on the platform display screen, and the high travel speed will be reduced. Stop the machine immediately and fully charge the battery.

NOTICE

- The machine is delivered with a battery level less than 80%, so it is recommended that the battery is fully charged once the machine has been delivered.
- The charging current must not exceed the maximum allowable charging current indicated on the battery.
- The charging voltage must not exceed the maximum allowable voltage indicated on the battery.
- The battery charging temperature range is -10 °C to 45 °C. If equipped with a charging heating system, the charging temperature range is -20 °C to 45 °C.
- Battery over-discharge (continued use of battery with levels of less than 10%) or battery under-voltage caused by long-term non-charging (battery with levels of less than 10% not charged for more than three days), resulting in battery capacity attenuation and failure, are not covered by the warranty.
- It is recommended not to use a lead acid battery with an ambient temperature below 0 °C; otherwise the battery capacity will decay rapidly, and battery life will be affected.

Charging lead-acid (maintenance required) batteries

1. Checking the battery level.

- Check the battery level on the screen of the platform controller. When the battery level is $\leq 20\%$, the low battery alarm will be triggered and the battery needs to be charged immediately. To avoid affecting the normal performance of the machine it is recommended to charge the battery when the battery level is below 30 %.

- As an alternative means of determining the battery status, open the cover on the battery and measure the density of the electrolyte. If the density of the electrolyte is less than 1.13 kg/l the battery has been over-discharged (discharge depth exceeds 80 %) and must be charged immediately. This should be avoided, as frequently over-discharging the battery will reduce its service life.

NOTICE

Measure the temperature of the electrolyte. If it exceeds 45 °C wait for the battery to cool before proceeding to the following steps.

- Completely power off the machine.
- Connect the plug between the battery and the charger cable. If the machine is equipped with an automatic liquid refilling system, ensure that the refilling pipe is connected.
- Connect the battery charger to a grounded AC circuit. The indicator light will illuminate steadily once the battery is fully charged.
- After charging is complete, disconnect the cable plug from the battery to the charger.


Charging maintenance-free batteries

- Check the battery level on the screen of the platform controller. When the battery level is $\leq 20\%$, the low battery alarm will be triggered and the battery needs to be charged immediately. To avoid affecting the normal performance of the machine it is recommended to charge the battery when the battery level is below 30 %.
- Completely power off the machine.
- Connect the battery charger to a grounded AC circuit. The indicator light will illuminate steadily once the battery is fully charged.
- After charging is complete, disconnect the cable plug from the battery to the charger.

Description of Battery Level Indications

The battery level indication on the platform display is as follows:

Table 7-1

Platform battery level indication	State of charge	Description
	90-100 %	The battery has been fully charged.
	70 %	The battery is at 70 % of its capacity.
	50 %	The battery is at 50 % of its capacity.
	30 %	The battery is at 30 % of its capacity.
	20 %	The battery level is at 20 %, which is low. The battery should be charged immediately.
	10 %	The battery level is at 10 %, which is extremely low. The machine will move slowly. The battery should be charged immediately.

Charging Display

- Once the charger is connected to mains supply the LED light will flash, and the default code for the charging curve will be displayed.
- Once the curve code is displayed the charger will enter the charging mode.
- In charging mode, the charging indicator illuminates in different modes based on the charging progress.
 - With a battery level of less than 50% the 50% indicator flashes at low frequency;
 - With the battery level between 50% and 75% the 75% indicator flashes at high frequency;
 - With the battery level between 75% and 100%, the 100% indicator illuminates steadily;
 - In case of a battery failure, the battery fault indicator on the charger will illuminate steadily.

Charging with Range Extender (if equipped with range extender)

The machine is equipped with a range extender, consisting of a diesel engine, a generator and an electric motor controller. The diesel engine drives the generator to charge the battery by means of the electric motor controller.

The machine's main control system controls the range extender controller remotely. When the main control system gives a start or stop order, the range extender controller, after receiving the order, starts to operate or stop operating.

Automatic charging mode

1. After the machine is powered on, the default charging mode is manual mode, and the symbol "M" will be displayed on the display screen.
2. Pull out the emergency stop button on the range extender to the ON position.
3. Change charging mode:
 - Operate from ground control position: Press the charging mode selector switch, the switch indicator light will illuminate and the machine will change to automatic charging mode with the symbol "A" displayed on the screen. Press the charging mode selector switch again, the switch indicator light will go out and the machine will exit automatic charging mode with the symbol "M" displayed on the screen.
 - Operate from platform control position: Press the charging mode selector switch, the switch indicator light will illuminate and the machine will change to automatic charging mode with the battery level and the symbol "A" displayed alternatively on the screen. Press the charging mode selector switch again, the switch indicator light will go out and the machine will exit automatic charging mode with the symbol "M" displayed on the screen.
4. In automatic charging mode, when the SOC drops to less than 30%, the range extender will charge the battery automatically.
5. To interrupt the charging status, process as follows:
 - Method 1: Press the emergency stop button on the ground controller and platform controller to "OFF" position.
 - Method 2: Press the range extender manual start switch, the machine will exit automatic charging mode, and the range extender will stop charging the battery with the symbol "M" displayed on the screen.
6. In automatic charging mode, when the SOC increases to more than 80%, the range extender will stop charging the battery.

Manual charging mode

1. After the machine is powered on, the default charging mode is manual mode, and the symbol "M" will be displayed on the display screen.
2. Pull out the emergency stop button on the range extender to the ON position.
3. When the SOC drops to less than 80%, press the "range extender manual start switch" from the ground control position or platform control position to start the range extender. Then the range extender starts to charge the battery.
4. To interrupt the charging status, process as follows:
 - Method 1: Press the emergency stop button on the ground controller and platform controller to "OFF" position.
 - Method 2: Press the range extender manual start switch, the machine will exit automatic charging mode, and the range extender will stop charging the battery with the symbol "M" displayed on the screen.
5. When the SOC increases to more than 80%, the range extender will stop charging the battery.

NOTICE

- The charging package is subject to the ambient temperature. In summer season or normal temperature environments, it can be started immediately, but in winter season or low temperature environments, 5s start delay and then 5s preheat delay are required before it can be started. For detailed start time setting methods, refer to the **Maintenance Manual**.
- For machines configured with 15s anti-repeated start function, if the range extender fails to start after the range extender manual start switch is pressed, wait 15s before pressing this switch again.

7.5 LIFTING AND LOWERING THE PLATFORM



WARNING

If the tilt alarm is triggered, stop operation and fully lower the platform. Do not start operation again unless the tilt cause has been corrected.

Perform Operations on the Ground

1. **Raise the platform:** Press and hold the Enable key on the joystick and press the Platform Up key. The platform should lift.

2. **Lower the platform:** Press and hold the Enable key on the joystick and press the Platform Down key. The platform should descend.

Perform Operations on the Platform

- **Activate platform lift and lower mode:** Press the platform lift and lower function enable switch: the switch indicator will illuminate. The machine will enter the platform lift and lower mode.

Note: When performing operation from the platform, the lifting speed of the platform is in direct proportion to the travel distance of the joystick. The shorter the travel distance, the slower the speed.

1. **Raise the platform:** Press and hold the enable switch on the joystick and push the joystick forward. The platform should lift.
2. **Lower the platform:** Press and hold the Enable switch on the joystick and pull the joystick back. The platform should descend.

Note: While using the platform controller to lower the platform in the operating position, after the platform has reached the non-operating position, it will automatically stop lowering. The operator must restart the platform lowering function (release the joystick, return to the neutral position, and then turn the joystick again). The platform will continue to descend after 5 s.

7.6 TRAVELING

WARNING

- The machine must not travel with the platform raised unless it is on a firm and flat surface without exceeding the maximum allowable climbing angle.
- The machine must not be driven on slopes, steps or arched surfaces that exceed the maximum gradeability of the machine.
- Extreme care must be taken when driving the machine in reverse or with the platform raised.
- When driving the machine in potentially dangerous situations such as driving on slopes or reversing, operate the handle in small increments to avoid danger due to excessive speed.

Activate Drive and Steer Mode

- Press the drive and steer function enable switch, the indicator light will illuminate. The machine will enter drive and steer mode.

Drive Forward and Reverse

Note: The travel speed is in direct proportion to the travel distance of the joystick. The shorter the travel distance, the slower the speed.

1. Activate the drive and steer mode.
2. **Driving forward:** Press and hold the enable switch on the joystick and push the joystick forward. The machine will move forward.
3. **Driving reverse:** Press and hold the enable switch on the joystick and pull the joystick back. The machine will move in reverse.
4. **Braking:** While the machine is traveling: when the joystick is released the machine should stop.

Steering While Traveling

1. Activating drive and steer mode.
2. **Steer left:** Press and hold the Enable switch on the joystick, push the joystick forward and press the left button on the top of the joystick with your thumb – the machine will steer left.
3. **Steer right:** Press and hold the Enable switch on the joystick, push the joystick forward and press the right button on the top of the joystick with your thumb – the machine will steer right.

Travel on Slopes

WARNING

The machine must not be driven on slopes, steps or arched surfaces that exceed the maximum gradeability of the machine.

Before traveling on a slope, please determine:

1. The machine's maximum gradeability.
2. The slope grade. To determine the slope grade:
 - Use a suitable carpenter's ruler, a straight piece of wood and a tape measure.
 - Measure the height (H) and length (L) of the slope.




Fig. 1

- Slope grade= $H/L \times 100\%$.

High and Low Travel Speed Switching

WARNING

- In a tilted condition the machine must be driven at low speed.
- Before traveling at high speeds, make sure to first observe whether the surrounding environment is safe. Otherwise, it is possible that collisions and other hazards may occur with obstacles or other people.

DTC K120 control system:

1. With the machine in non-operating position, press the turtle speed button – the button indicator will illuminate and the machine switches to travel at low speed.

NOTICE

With the machine in non-operating position, the turtle speed button turned off and the engine in high speed state (if equipped with engine), activate the travel function and push the joystick, the machine will start to travel at high speed immediately, and pushing the joystick to full drive position will bring the machine to the maximum travel speed.

2. With the machine in operating position, the travel speed of the machine will be reduced to the elevated travel speed automatically.

Sinoboom control system:

1. With the machine in non-operating position, press the creep mode enable switch – the button indicator will illuminate and the machine switches to travel at low speed.

NOTICE

With the machine in non-operating position, the creep mode enable switch turned off and the engine in high speed state (if equipped with engine), activate the travel function and push the joystick, the machine will start to travel at high speed immediately, and pushing the joystick to full drive position will bring the machine to the maximum travel speed.

2. With the machine in operating position, the travel speed of the machine will be reduced to the elevated travel speed automatically.

7.7 OUTRIGGER LEVELING

WARNING

- The outrigger leveling function can only be activated while the machine is in stowed position.
- Never operate the outrigger leveling if the platform is overloaded.

Automatic leveling

1. Press the outrigger auto leveling enable switch, the automatic outrigger leveling mode will be activated.
2. Press and hold the enable switch on the joystick and pull the joystick back. The outriggers will be extended.
3. When an outrigger contacts with the ground, the corresponding outrigger leveling enable switch indicator will illuminate.
4. Once all four outriggers contact with the ground, the automatic leveling will begin.
5. After the outriggers are leveled, the buzzer will sound for 3 s, and the outriggers will stop extending.
6. Press and hold the enable switch on the joystick and push the joystick forward slowly. The outriggers will be retracted.
7. Once an outrigger is off the ground, the corresponding outrigger leveling enable switch indicator will go out.

Manual leveling for individual outrigger

To adjust an individual outrigger manually, refer to the automatic leveling procedure.

Note:

- For 1323 model: When any outrigger is extended and contacts with the ground, but the four outriggers haven't been leveled, the machine maximum lift height will be restricted to the height where the down limit switch disengages.
- For 1623 model:
 - Condition 1: When the outriggers are not extended, the maximum platform height is limited to 9 m.
 - Condition 1: With the machine within the maximum allowable tilt angle and all outriggers rest on the ground but are not leveled, the maximum platform height is limited to 9 m.
 - Condition 2: After all four outriggers have been extended to the ground and leveled, the machine can be lifted to the maximum platform height.

- In other conditions, the machine maximum lift height is restricted to the height where the down limit switch disengages.
- If any outrigger touches the ground, the drive and steer functions will be disabled.

7.8 EXTEND AND RETRACT PLATFORM

WARNING

- While extending the platform, do not stand on the platform extension.
- Do not lower the platform if the platform extension has not been fully retracted.
- Do not work on the platform extension while it has not been secured.




Fig. 2

Extend the platform:

1. Remove the index pin #1.
2. Lift up the locking handle #2 to horizontal position.

3. Grip the locking handle and push towards the platform extending direction to extend the platform extension.
4. Once the platform extension is extended to the desired position, release the locking handle #2 and re-install the index pin #1 to secure the platform extension.

Retract the platform:

1. Remove the index pin #1.
2. Lift up the locking handle #2 to horizontal position.
3. Grip the locking handle and push towards the platform retracting direction to retract the platform extension.
4. Once the platform extension is retracted to the desired position, release the locking handle #2 and re-install the index pin #1 to secure the platform extension.

7.9 FOLD AND UNFOLD PLATFORM GUARDRAILS

The platform guardrails can be folded for convenient transportation.

WARNING

- Do not raise the platform while the guardrails are folded down. The guardrails must be unfolded and secured properly while the platform is lifting.
- Fold down/unfold the guardrails only when the machine is stowed and the platform extension is fully retracted.
- Do not reach hands and arms near areas where they may be crushed.
- With the platform guardrails folded down, if the machine is to be started from the ground with the platform controller, the operator should maintain a safe distance of at least 1 m (3 ft) from the machine.

Fold down the platform guardrails:




Fig. 3

1. Remove the platform controller and its bracket.
2. Remove the two wire rope safety pins at the front and rear guardrails, and fold down the guardrails towards platform inside.
3. Remove the two wire rope safety pins and limit rope cappelts at the left and right inner guardrails, and fold down the guardrails towards platform inside.
4. Remove the two wire rope safety pins at the left and right outer guardrails, and fold down towards platform inside.

Unfold the platform guardrails:

Unfold the platform guardrails in the reverse order of the fold-down instructions.

7.10 TURNING OFF AND STOPPING

1. Park the machine on a firm, flat, and level surface, and make sure the area is adequately protected.

2. Make sure that platform has been completely lowered, and remove all loads from the platform.
3. Press the emergency stop buttons on the ground controller and platform controller, turn the ground/platform control selector switch to the Neutral position, and remove the key (if equipped).
4. Close the platform controller guard to protect the platform controller and its handles, switches and panels from damage by harsh environments.
5. If the machine will not be used for a prolonged period of time, press the power-off switch to OFF or pull out the power-off handle.
6. Make sure that all panels and gates are closed and secured.

7.11 TRANSPORT AND LIFTING

The mobile elevating work platform is a non-road vehicle and is not licensed for on-road use, so the machine needs to be transported and transferred by road, railway or waterway.



WARNING

Only qualified individuals may drive the machine onto or from the transport vehicle.

Before transporting and lifting the machine:

1. Determine the total weight of the machine (see machine nameplate or **Technical Parameters** section of this manual) and select the appropriate lifting equipment, rigging equipment, and transport vehicle.
2. Make sure that the machine is in transport position, the machine has no loose or unfixed parts, and that no people or any tools are on the platform.
3. Ensure that the machine lifting points/rigging equipment lashing points and their rigging equipment are intact and that the belt or rope to be used has sufficient load strength.
4. Before loading/unloading the machine, ensure that the transport vehicle is parked on level ground and that the ramp used for driving the machine onto the transport vehicle does not exceed the maximum gradeability of the machine.
5. When loading/unloading the machine, the transport vehicle must be secured to prevent it from moving.
6. The wheels should be locked after the machine is loaded to prevent it from moving.
7. Before releasing the brake, the machine must be parked on a horizontal surface or secured.
8. The machine may only be lifted from a specific position with a forklift or crane with sufficient lifting capacity. Care should be taken to prevent the machine from colliding with surrounding objects.

Transport

1. Adjust the machine to the transport position.
2. On the ground controller, switch the "ground/platform control selector switch" to "neutral" position, and remove the key (if equipped).
3. Use at least 2 ropes or belts at the lashing points shown in the figure below to securely fix the chassis to the transport vehicle, and take appropriate safety protection measures.
4. Adjust the rigging appropriately to prevent damage to the rope or belt.




Fig. 4 Transport Diagram

Lifting

1. Determine the center of gravity of the machine.
2. The rigging equipment must be attached to the machine's specified lifting point.
3. Adjust the rigging equipment properly to avoid damage to the machine and keep the machine level.

1323RE:

X=1.39 m (4.56 ft)

Y=1.08 m (3.54 ft)

1623RE:

X=1.53 m (5.02 ft)

Y=0.95 m (3.12 ft)




Fig. 5 Diagram of Center of Gravity and Lifting with Rigging Equipment

A forklift may be used to lift the machine.

1. Align the forklift forks to the positions indicated by the arrows in the diagram below.
2. Drive the forklift forward to fully insert the forks into the pockets.
3. Lift the machine by 0.4 m (16 in) and then tilt the forks backward slightly to keep the machine stable.
4. Keep the machine horizontal when lowering the fork frame.




Fig. 6 Diagram of Lifting with Forklift

7.12 STORAGE

Mobile elevating work platforms should be stored in places that are protected from rain, humidity, sunlight, or corrosive gases, and that have good ventilation.

In order to ensure the machine can be operated normally after prolonged storage the following measures should be taken when storing the machine:

1. Lower the platform to the stowed position.
2. Press the Stop key and emergency stop button on the range extender.
3. Press the emergency stop buttons on the ground controller and platform controller, turn the ground/platform control selector switch to the Neutral position, and remove the key (if equipped).
4. Press the power switch/pull out the power handle.
5. Chock the wheels.
6. Wipe off all dust and oil from the machine to keep it clean.
7. Apply lubricating oil to parts prone to corrosion.
8. When long-term storage is required, the hydraulic oil, fuel and coolant should be drained, the positive pole and negative pole of the battery should be disconnected, and insulation protection measures shall be taken.
9. Close and lock all panels and gate locks on the machine.
10. For a machine stored for more than three months, idle the machine every three months for not less than one hour each time, and clean and maintain the machine.
11. For a machine stored for more than one and a half years, a comprehensive inspection and maintenance on the machine should be carried out before use, aging seals and filter elements should be replaced as appropriate.

8

EMERGENCY PROCEDURES

8.1 REPORTING ACCIDENTS

In case of any accident involving Hunan Sinoboom Intelligent Equipment Co., Ltd. products, Hunan Sinoboom Intelligent Equipment Co., Ltd. must be notified immediately. In case of any accident involving the machinery of Hunan Sinoboom Intelligent Equipment Co., Ltd., notify Hunan Sinoboom Intelligent Equipment Co., Ltd. by telephone immediately and provide all necessary details, even if the accident did not cause personal injury or property damage.

Failure to notify the manufacturer within 48 hours of the incident involving the machinery of Hunan Sinoboom Intelligent Equipment Co., Ltd. may void the product warranty.

NOTICE

Thoroughly inspect the machine and all its functions after any accident. First, test all functions from the ground controller, then from the platform controller. Ensure the machine's lifting height does not exceed 3 m (10 ft) until all damage has been repaired and all controllers operate properly.

This chapter describes the steps to follow in the event of unexpected situations during operation.

8.2 EMERGENCY OPERATION

When the operator is unable to control the machine (squeezed or trapped on the platform):

1. Other personnel can only operate the machine with the ground controller according to the operation requirements.
2. Other qualified operation personnel on the platform can operate the platform controller. If the controller is not working properly, do not continue to operate.
3. Hoists, forklifts or other equipment that meet the requirements of use can be used to transport people on the platform and stabilize the movement of the machine.

When the platform is stuck at height:

If the platform is stuck or blocked by high buildings or aerial equipment, rescue the operator on the platform first and then get the machine out.

If any switch is reset but the movement does not stop:

If any switch/handle returns to the neutral position but the corresponding movement does not stop, push in the emergency stop button to stop the machine.

8.3 EMERGENCY LOWERING

NOTICE

The emergency lowering combined keys shall only be used for a short time (to fully lower the platform from the maximum height) when the main power source can not function.

When the main power source fails, the emergency lowering combined keys on the ground controls can be used according to the actual condition to lower the platform into place.

8.4 EMERGENCY TOWING

WARNING

- Except in case of emergency situations, machine malfunction, power loss or loading/unloading, it is strictly prohibited to tow or drag the machine.
- When towing or dragging the machine, comply with local policies and road traffic regulations.
- Towing the machine on public highways is prohibited.
- The machine is not equipped with a brake for towing control, so the towing vehicle must be able to control the machine at all times, otherwise the machine may lose control, resulting in serious injury or death.
- The maximum permissible towing speed is 3 km/h (1.9 mph).
- The maximum permissible towing gradient is 25 %.
- The machine must not be towed/dragged when the brake has not been released or the machine is started.
- Before the brake is released, the machine must be parked on a horizontal surface or secured.

1. Place the machine on solid level ground and secure the wheels with chocks to prevent the machine from moving inadvertently.
2. Make sure that the machine is in stowed without loose or unsecured objects, and there are no people or tools in the platform and no obstacles in the surrounding area.
3. Loosen the bolts of disconnect cap on the side of drive reducer, and then install the disconnect cap in the reverse position.

A Normal position - engaged

B Reverse position - disengaged

- 1) Drive reducer
 - 2) Disconnect cap (normal position)
 - 3) Disconnect cap (reverse position)
4. Tighten the bolts, the brake is separated, the brake is released, the machine can be towed or dragged by an external force.
 5. After towing, place the machine on firm, level ground and secure the wheels with chocks to prevent the machine from moving.
 6. Reinstall the disconnect cap to the side of drive reducer in the normal position.





Fig. 1

9 DECALS DIAGRAM



No.	ANSI & CSA	CE-Metric	CE-Imperial	AS	GB	Description	Quantity
	115007100005	115007100015	115007100006	115007100002	115007100001	General decals diagram - 1323RE	1
	115008100005	115008100007	115008100006	115008100002	115008100001	General decals diagram - 1623RE	1
1	216060000004	216060000004	216060000004	216060000004	216060000004	Yellow and black striped hazard warning tape, 50mm wide	9
2	101048103025	101048103025	101048103025	101048103025	101048103025	LOGO SINOBOOM	2
3	115007100013	115007100011	115007100011	115007100011	115007100011	Decal - Requirements of use (1323RE-2)	2
	115008100013	115008100011	115008100011	115008100011	115008100011	Decal - Requirements of use (1623RE-2)	2
4	115006103017	115006103002	115006103002	/	115008100016	Decal – Tipping hazard	2
5	101040103013	/	/	/	/	Decal – Electrocutation hazard	3
6	101012100001	/	/	/	/	Decal - No smoking or open flames	2
7	102013103007	102013103002	102013103002	102013103002	102013103002	Decal - Outtrigger ground load 3200kg	4
8	102001100003	102001100003	102001100003	102001100003	102001100003	Decal – Crushing hazard	4
9	102013103006	102013103001	102013103001	102013103001	102013103001	Decal - Tire ground load 3900kg	4
10	102001103016	102001103016	102001103016	102001103016	102001103016	Decal - Large logo in white	2
11	101016100034	101016100034	101016100034	/	/	Decal – Noise level of 72dB	2
12-1	101014100016	101014100016	101014100016	/	/	Decal – Electrocutation hazard	2
12-2	/	/	/	101014100016	101014100016	Decal – Electrocutation hazard	2
13	102004100022	102004100022	102004100022	/	/	Decal – Tipping hazard	1
14-1	102015100014	/	/	/	/	Decal – Tipping hazard	2
14-2	/	102015100014	102015100014	/	/	Decal – Tipping hazard	2
15	101012100012	101012100012	101012100012	101012100012	101012100012	Decal - High pressure hazard	1
16	101079103015	101079103015	101079103015	101079103015	101079103015	Decal - Platform power plug	2
17	115005103003	115005103002	115005103003	115005103002	115005103002	Decal – Trade name 1323RE	2
	115006103004	115006103003	115006103004	115006103003	115006103003	Decal – Trade name 1623RE	2

No.	ANSI & CSA	CE-Metric	CE-Imperial	AS	GB	Description	Quantity
18	101012100030	101012100030	101012100030	101012100030	101012100030	Decal – General maintenance	1
19	101012100027	101012100027	101012100027	/	/	Decal – Refer to the manuals	1
20	101079103017	101079103017	101079103017	101079103017	101079103017	Decal – Crushing hazard	2
21	104011100021	104011100021	104011100021	/	/	Decal – Crushing hazard	2
22	101040103015	/	/	/	/	Decal – Annual inspection date	1
23	102012103009	/	/	102012103009	/	Decal – Hydraulic oil marking	1
24	103006103014	103006103014	103006103014	103006103014	103006103014	Decal – Anchorage point	12
25	101014100026	101014100026	101014100026	101014100026	101014100026	Decal - Safety strut	1
26	101079103016	101079103016	101079103016	102004100015	101079103016	Decal – General safety instructions	1
27	102001103008	102001100005	102001100005	102001100005	102001100005	Decal – Tipping hazard	1
28	115007100012	115007100010	115007100010	115007100010	115007100010	Decal - Requirements of use (1323RE-2)	1
	115008100012	115008100010	115008100010	115008100010	115008100010	Decal - Requirements of use (1623RE-2)	1
29	103010103014	/	/	/	/	Decal – Non-insulated	1
30	101079103010	101079103010	101079103010	101079103010	101079103010	Decal – Lifting point and lashing point	4
31	102004100008	102004100008	102004100008	102004100008	102004100008	Decal - Lashing point	2
32	104011100016	104011100016	104011100016	104011100016	101056103002	Decal - Main power switch	1
33	101014100032	101014100032	101014100032	101014100032	101014100032	Decal - Machine serial number	2
34	215050000012	215050000012	215050000012	215050000012	215050000012	Blind rivet 4×8-ZnD GB/T 12618.2	4
35	102001103018	102015100013	102015100013	102001103002	102001103001	Nameplate	1
36	104011100010	104011100010	104011100010	104011100010	104011100010	Decal – Hydraulic oil level	1
37	104011100003	104011100003	104011100003	104011100003	104011100003	Decal – Hydraulic oil level	1
38	101055103015	104011100016	104011100016	101055103015	101055103016	Decal – Emergency stop button	1
39	/	/	/	101012100007	/	Decal – Tipping hazard	1
40	/	/	/	101040100002	/	Decal – Refer to the manuals	1

No.	ANSI & CSA	CE-Metric	CE-Imperial	AS	GB	Description	Quantity
41	/	101079103034	101079103034	/	/	Decal – Handle hold position	8
42	/	101086103013	101086103013	/	/	Decal – Crushing hazard	4
43	/	/	/	/	101062103028	Decal - Service number + enquiry QR code	2
44	/	/	/	115006103002	/	Decal – Tipping hazard	2
45	/	/	/	101055103019	/	Decal – Electrocution hazard	2
46	/	101012100005	101012100005	/	101012100005	Decal – Electrocution hazard	3
47	/	/	/	101012100001	/	Decal - No smoking or open flames	2
48	/	101012100001	101012100001	/	101012100001	Decal - No smoking or open flames	2
49	/	102012103009	102012103009	/	102012103009	Decal – Hydraulic oil marking	1
50	/	/	/	102004100022	102004100022	Decal – Tipping hazard	1
51	/	/	/	101012100027	101012100027	Decal – Refer to the manuals	1

10 MAINTENANCE

This chapter provides the operator with additional information needed to properly operate and maintain the machine, and is only intended to assist the operator in performing routine maintenance tasks. For more comprehensive maintenance instructions, please refer to the **Inspection and Preventive Maintenance Schedule** and the Maintenance Manual.

10.1 LUBRICATION

In order to ensure the performance and service life of the machine and its components, moving parts must be regularly inspected and lubricated.

NOTICE

- *Mixing lubricating oil of different grades will alter its properties and cause damage to the machine. When refilling lubricant, the oil being added must be of the same grade as the oil currently in use in the machine.*
- *Any contamination (dust) of the lubricating oil can lead to premature wear of the sliding surfaces and shorten the service life of the machine. Before adding lubricating oil the container used for filling and other surfaces must be cleaned.*
- *Failing to adhere to lubrication cycles or lack of lubrication can cause equipment damage, and increase repair costs and downtime.*



WARNING

- **During the lubrication procedure, non-related personnel are prohibited from operating the equipment. Unexpected equipment movements could pose serious risks to the operator.**
- **If lubricating oil gets into the eyes, rinse the eyes immediately with clean water and seek medical attention promptly. If the skin comes into contact with lubricating oil, make sure to thoroughly wash the skin with water.**

Table 10-1

No.	Position	Interval	Lubricating oil/grease grade	Operation
1	Drive system components	Every 3 months or 250 operating hours	Refer to the Gear Oil section	Check oil level
		Every 1 year or 1000 operating hours		Replace oil

Lubrication intervals are based on machine usage under normal operating conditions. If the machine is used in rough (such as dusty environments) or other unusual conditions, inspection and lubrication should be performed more frequently.

10.2 OIL SPECIFICATIONS

NOTICE

- Please choose suitable oil according to the ambient temperature and local regulations; the use of unsuitable oil will damage the machine components.
- Oils of different grades or viscosities should not be mixed. When refilling oil, the oil being added must be of the same grade and viscosity as that of the oil currently in use in the machine.
- The oil recommendations in this manual are for general operating conditions. For special environments or special operating requirements please contact Sinoboom for special oil.



WARNING

- Before refilling oil, wait until the temperature of the machine drops to room temperature, otherwise it may cause splashes, burns or other personal injury.
- The use of inferior oils is strictly prohibited. Using inferior oil may damage the machine, and faults caused by this are not covered by Sinoboom's warranty.

Hydraulic Oil

Factory-filled hydraulic oil is usually based on the ambient temperature of the delivery place or as specified by customers. If the factory-filled hydraulic oil is not applicable for the machine operating environments, change to other hydraulic oil suitable for actual operating environment. The following table shows the recommended hydraulic oil grade for different ambient temperature ranges:

Table 10-2

Ambient temperature range	Hydraulic oil grade
> 40°C (104°F)	Sinopec HM-68
0°C – 40°C (32°F – 104°F)	Sinopec HM-46
-15°C – 25°C (5°F – 77°F)	Sinopec HV-32

Table 10-2 (continued)

Ambient temperature range	Hydraulic oil grade
-22°C – 25°C (-7.6°F – 77°F)	Sinopec L-HS32
< -22°C (-7.6°F)	Sinopec AE-VX

Gear Oil

This machine is filled with heavy-duty vehicle gear oil (GL-5). Choose the oil viscosity grade that suits your region's ambient temperature. The following table shows the recommended ambient temperature for different viscosity grades of gear oil:

Table 10-3

Viscosity grade	Recommended ambient temperature
75W-90	-35 – 40°C (-31 – 104°F)
80W-90	-25 – 40°C (-13 – 104°F)

Note: Sinoboom recommends Mobil gear oil.

Fuel Oil



WARNING

- The machine should be refueled in a well-ventilated place with no flames, sparks, and other hazards that may cause fire or explosion.
- Do not refuel the machine while the engine is running.

This machine uses diesel oil as the fuel, and only a small amount of diesel oil is left in the fuel tank when the machine leaves the factory. The user needs to fill diesel oil timely with appropriate grade according to the ambient temperature and emission regulations. The following table shows the recommended ambient temperature for different grades of diesel oil:

Table 10-4

Grade	Recommended ambient temperature
0#	0 – 40°C (32 – 104°F)
-35#	-30 – 25°C (-22 – 77°F)

NOTICE

Please go to a certified gas station to purchase qualified fuel oil. It is recommended prepare an oil storage tank with fuel filter and store the fuel oil in the tank for more than two days to precipitate impurities and water before use.

Engine Oil

Engine oil should be selected based on the engine type and the local ambient temperature. The table below shows the recommended engine oil for different types of engine:

Table 10-5

Engine type	Recommended service category*	Recommended viscosity grade**
Engines meeting China III emission standards	CH-4	5W-40/15W-40
Yanmar engines meeting China III emission standards	CJ-4	5W-40/15W-40
Engines meeting China IV, Euro V and EPA Tier 4 emission standards	CJ-4/CK-4	5W-40/15W-40

*The letters "H", "J" and "K" represent engine oil service category, and the oil specifications become more severe as the letters climb the alphabet. Select appropriate engine oil based on the table recommendations above, which shall be at least not lower than the recommended service category.

**Engine oil with viscosity grade 5W-40 is suitable for ambient temperature range -25 – 25°C (-13 – 77°F), and that with viscosity grade 15W-40 is suitable for ambient temperature range 0 – 40°C (32 – 104°F). Select engine oil with viscosity grade that suitable for your local ambient temperature.

Antifreeze

Factory-filled antifreeze is based on engine brand:

Table 10-6

Engine brand	Antifreeze type
Deutz	-45°C antifreeze
Yanmar	-40°C antifreeze
Other brands	-35°C antifreeze

The antifreeze types above could meet the requirements of areas with ambient temperature range 35 – 40°C (-31 – 104°F). If the machine is to be operated in special environments where the above antifreeze types are not applicable, contact Sinoboom for appropriate antifreeze.

Check Tires and Rims

Check the tires and rims daily and replace a tire if any of the following defects is found:

- The tire is severely cracked, broken, deformed or shows other abnormalities.
- The tire ply shows a smooth, uniform cut with a total length of more than 75 mm (3 in).
- The tire ply shows a crack or fissure that exceeds 25 mm (1 in) in either direction.
- The tire has a puncture with a diameter of more than 25 mm (1 in).
- The tire shows severe bulging.
- The wear extent of the tire's ground-supporting surface exceeds 25 %.

10.3 TIRE ASSEMBLY

NOTICE

Non-marking tires shall be used indoor only on ground sufficient to support the total mass of the machine (machine weight + platform load).




Fig. 1

Check Wheel Nuts

The wheel nuts should be tightened before the machine is put into service for the first time and after each tire is removed. Check and tighten the wheel nuts to the specified torque every 3 months or 250 operating hours.

Replacement Requirements

WARNING

- The tires and rims on the machine have been designed and selected according to the overall performance and load stability requirements of the machine. Therefore, the model specifications, rim width, installation center surface, diameter, etc. must not be changed, otherwise this could lead to an unstable and hazardous condition.
- Wheel-specific nuts must be used that match the wheel bolts. The wheel nuts must be installed and maintained with the proper tightening torque to prevent loose rims, broken bolts and wheels loosening from the axle. Be sure to only use nuts that match the mounting angle of the rim holes.

Hunan Sinoboom Intelligent Equipment Co., Ltd. recommends the replacement tire be of the same size, ply rating and brand as the original tire. For the tire part numbers of specific machine models, please refer to the Parts Manual of the corresponding machine. If you choose not to use the replacement tires recommended by Hunan Sinoboom Intelligent Equipment Co., Ltd., the following specifications should be adhered to:

- The ply rating/rated load capacity and size should be the same as the original tire or superior to it.
- The tire tread contact width should be the same as or superior to the original tire.
- The wheel diameter, width and offset dimensions must be the same as the original tires.
- The replacement tire must be approved for the application by the tire manufacturer (including intended purpose, maximum travel speed, maximum tire load, etc.).
- Due to size differences between different tire brands, both tires on the same axle should be of the same brand.

NOTICE

Unless specifically approved by Sinoboom, do not replace foam-filled tires with pneumatic tires.

Replace Tire and Wheel Assembly

WARNING

Tighten the wheel nuts to the specified torque to prevent the wheel from loosening. Use a torque wrench to tighten the nuts. If no torque wrench is available use a socket wrench to tighten the nuts and then immediately have a service station or dealer tighten the nuts to the specified torque. Over-tightening will cause the nuts to break or permanently deform the bolt holes in the rims.

The correct steps to replace a tire and wheel assembly are as follows:

1. Make sure the machine is in stowed position.
2. Turn the power switch off and disconnect all power sources (such as battery charger) from the machine.
3. Use a wrench to loosen but do not remove the wheel nuts yet.
4. Use a jack with sufficient load capacity to lift the frame to an appropriate height so that the tire and wheel assembly is off the ground.
5. Remove the wheel nuts in an alternating sequence, then remove the tire and wheel assembly.
6. Align the mounting holes of the new tire and wheel assembly with the corresponding mounting holes on the drive reducer.
7. Apply Loctite 272 thread locking adhesive to the bolts and nuts, then install the nuts in sequence.
8. Tighten all nuts by hand first to prevent loosening of the bolts and nuts. Never apply lubricant to threads or nuts.

9. Then tighten the nuts step by step in the sequence as shown below. Please refer to the recommended torque settings in the table below.




Fig. 2 Diagram – Wheel Nuts Tightening Sequence

Table 10-7 Table of Wheel Nuts Tightening Torque

First step	Second step	Third step
150 Nm (110 ft-lb)	210 Nm (155 ft-lb)	265 Nm (196 ft-lb)

10.4 INSPECTION AND PREVENTATIVE MAINTENANCE SCHEDULE

This section provides safety and other vital information for machine operators. To extend the service life of the machine and ensure safe operation, all necessary inspections and maintenance work must be completed before the machine is put into service.

It is crucial to develop and adhere to a comprehensive inspection and preventive maintenance program. This manual outlines the regular inspections and maintenance procedures recommended by Hunan Sinoboom Intelligent Co., Ltd. Consult your national, regional or local regulations for aerial work platforms. The frequency of the inspection and maintenance must be increased as required by environmental conditions, requirements and frequency of usage.

Pre-delivery Inspection (PDI)

The pre-delivery inspection shall be performed by qualified Sinoboom technicians.

A pre-delivery inspection shall be performed before each sale, lease or rental delivery.

Refer to the **Inspection and Preventive Maintenance Schedule** for items requiring a PDI. Refer to the corresponding section of this manual to perform inspection and maintenance procedures.

Pre-operation Inspection

A pre-operation inspection must be performed before each start or restart of work, change of operator, and after each maintenance operation. Refer to the pre-operation inspection section of the Operation Manual for detailed information. The Operation Manual must be entirely read and understood before performing the pre-operation inspection.

Regular Inspections

Regular inspections shall be performed by qualified Sinoboom technicians.

Regular inspections must be performed after the machine has been in service for 3 months or 250 hours, whichever comes first, or if it has been out of service for more than 3 months. The frequency of the inspection and maintenance must be increased as required by environmental conditions, requirements and frequency of usage.

The items included in the regular inspections are identical to the pre-delivery inspection.

Annual Inspection

An annual machine inspection must be performed once a year and no later than 13 months from the date of the previous annual inspection. Hunan Sinoboom Intelligent Equipment Co., Ltd. recommends this task be performed by a factory-trained service technician, a person recognized by Sinoboom as one who, by qualification, certificate and training, has successfully demonstrated the ability and proficiency to service, repair and maintain the Sinoboom model in question.

Refer to the **Inspection and Preventive Maintenance Schedule** for items requiring annual inspection, and refer to the corresponding section of this manual to perform inspection and maintenance procedures.

Preventive Maintenance

Preventive maintenance procedures shall be performed by qualified Sinoboom technicians. The frequency of the inspection and maintenance must be increased as required by environmental conditions, requirements and frequency of usage.

Refer to the **Inspection and Preventive Maintenance Schedule** for items requiring a PDI. Refer to the corresponding section of this manual to perform inspection and maintenance procedures.

Responsible Persons and Qualifications for Performing Inspection and Maintenance

Table 10-8

Inspection Type	Inspection Frequency	Primary Responsible Persons	Service Qualifications
Pre-operation Inspection	Before starting/restarting work, change of user, after each maintenance activity.	User or operator	Properly trained user or operator
Pre-delivery Inspection (PDI)	Before each sale, lease or rental delivery	Owner, dealer or user	Qualified Sinoboom technician
Regular Inspections	In service for 3 months or 250 hours (whichever comes first) or out of service for more than 3 months	Owner, dealer or user	Qualified Sinoboom technician
Annual Inspection	Once a year and no later than 13 months from the date of the previous annual inspection	Owner, dealer or user	Factory-trained service technician
Preventive Maintenance	At intervals specified in the Inspection and Preventive Maintenance Schedule	Owner, dealer or user	Qualified Sinoboom technician

Inspection and Preventive Maintenance Schedule

Perform inspection and preventive maintenance for the items in the table below at the specified intervals. Maintenance and inspection intervals are calculated based on the months of service or the “accumulated operating hours” (cumulative working time) displayed on the ground controls (whichever comes first).

Inspection intervals are based on the use of the machine under normal operating conditions. The intervals should be shortened accordingly when operating in harsh environmental conditions.

Table 10-9 Inspection and Preventive Maintenance Schedule

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Platform assembly			
Platform	1	1	1
Guardrails and floor	2	2	2
Access gate	1, 2, 3	1, 2, 3	1, 2, 3
Locking handle for platform extension	1, 2, 3	1, 2, 3	1, 2, 3
Platform wear pads (at the connection with scissor arm) and fasteners	1, 2	1, 2	1, 2
Safety belt anchorage point	1, 2, 7	1, 2, 7	1, 2, 7
Scissor arms assembly			

Table 10-9 Inspection and Preventive Maintenance Schedule (continued)

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Scissor arms	1, 2	1, 2	1, 2
Safety strut	1, 2, 3	1, 2, 3	1, 2, 3
Bearings	1, 2, 5, 12	1, 2, 5, 12	1, 2, 5, 8, 12
Pivot pins, retaining rings and fasteners	1, 2	1, 2	1, 2
Chassis assembly			
Chassis	2	2	2
Chassis wear pads (at the connection with scissor arm)	1, 2, 5	1, 2, 5	1, 2, 5, 8
Tires	1, 2	1, 2	1, 2
Wheel nuts	1 ⁵⁰	1 ⁵⁰	1 ⁵⁰
Traveling and steering components	1, 2, 5	1, 2, 5	1, 2, 5
Bearings	1, 2, 5, 12	1, 2, 5, 12	1, 2, 5, 12
Chassis door at both sides	1, 2, 3	1, 2, 3	1, 2, 3
Ladder	1, 2, 5	1, 2, 5	1, 2, 5
Drive motor	1, 5, 6	1, 5, 6	1, 5, 6
Drive reducer	1, 2, 5, 6	1, 2, 5, 6	1, 2, 5, 6, 11
Electric motor	1, 2, 3, 6	1, 2, 3, 6, 13	1, 2, 3, 6, 13
Gear pump	1, 2, 3, 6	1, 2, 3, 6	1, 2, 3, 6
Power system			
Refer to the machine's maintenance manual for inspection and preventive maintenance schedule, and the engine manual provided with the machine for detailed instructions.			
Hydraulic system			
Hydraulic pump	1, 2, 3, 6	1, 2, 3, 6	1, 2, 3, 6
Hydraulic cylinder	1, 2, 3, 5, 6, 12	1, 2, 3, 5, 6, 12	1, 2, 3, 5, 6, 12
Bleeding the oscillating cylinder (if equipped)	10 ^{NO.1}	10 ^{NO.1}	10 ^{NO.1}
Hydraulic valves	1, 2, 3, 5, 6	1, 2, 3, 5, 6	1, 2, 3, 5, 6
Counterbalance valve, check of the locking function (if equipped)	10 ^{NO.1}	10 ^{NO.1}	10 ^{NO.1}
Hydraulic hoses, pipelines and fittings	1, 2, 6	1, 2, 6	1, 2, 6
Hydraulic tank	1, 2, 3, 5, 6	1, 2, 3, 5, 6	1, 2, 3, 5, 6
Hydraulic tank air filter	1, 5, 6	1, 5, 6, 11	1, 5, 6, 11
Suction filter	1, 5, 6	1, 5, 6	1, 5, 6, 11

Table 10-9 Inspection and Preventive Maintenance Schedule (continued)

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Return filter (if equipped)	1, 5, 6, 11 ⁵⁰	1, 5, 6, 11 ⁵⁰	1, 5, 6, 11 ⁵⁰
Hydraulic oil high-pressure filter	1, 5, 6, 11	1, 5, 6, 11	1, 5, 6, 11
Hydraulic oil	5, 6	5, 6	5, 6, 11
Electrical system			
Electrical harness, connectors	1, 2	1, 2	1, 2
Battery	1, 2, 6, 9, 12	1, 2, 6, 9, 12	1, 2, 6, 9, 12
Electrolyte	6	6	6
Charging function	3	3	3
Instruments, gauges, switches, lamps, horn	1, 3	1, 3	1, 3
Functions and controls			
Platform controller	1, 3, 4, 7, 10	1, 3, 4, 7, 10	1, 3, 4, 7, 10
Ground controller	1, 3, 4, 7, 10	1, 3, 4, 7, 10	1, 3, 4, 7, 10
Function control lock, secondary guarding device and brake	1, 3, 10	1, 3, 10	1, 3, 10
Emergency stop button (ground and platform)	1, 3, 10	1, 3, 10	1, 3, 10
Limit switches and power switch	1, 3, 10	1, 3, 10	1, 3, 10
Overload limit function	1, 3, 10	1, 3, 10	1, 3, 10
Tilt alarm	1, 3, 10	1, 3, 10	1, 3, 10
Emergency lowering device	1, 3, 10	1, 3, 10	1, 3, 10
Drive function	1, 3, 10	1, 3, 10	1, 3, 10
Brake function	1, 3, 10	1, 3, 10	1, 3, 10
Other			
Operation Manual in the manuals compartment	10	10	10
All decals/labels complete, clear and secure	10	10	10
Annual inspection date of the machine	/	/	10
No unapproved changes or additions	10	10	10
All safety publications taken into account	10	10	10
General structural components and weldments	2	2	2
All fasteners, pins, protective guards and covers	1, 2	1, 2	1, 2

Table 10-9 Inspection and Preventive Maintenance Schedule (continued)

Item	Interval		
	Before each delivery ¹ or quarterly ²	Semiannually ³	Annually ⁴
Greasing and lubricating according to specifications	10	10	10
Functional test of all systems	10	10	10
Paint and appearance	5	5	5
Inspection date stamped on the chassis	/	/	10
Notify Sinoboom of machine ownership (change)	/	/	10

Note:
¹ Before each sale, lease or shipment delivery;

² In service for 3 months or 250 hours; or out of service for more than 3 months;

³ In service for 6 months or 500 hours;

⁴ Once a year and no later than 13 months from the date of the previous annual machine inspection;

⁵⁰ The first inspection shall be performed once the machine reaches 50 hours in service for the first time. This occurs only once in the service life of the machine.

²⁵⁰ The first inspection shall be performed once the machine reaches 250 hours in service for the first time. This occurs only once in the service life of the machine.

NO.1 Before the machine is put into service for the first time

Inspection activity (numerical codes):

1. Check for correct installation (accurate position, firmly installed, tightened to the specified torque)
2. Visual inspection for damage (cracks, cracked welds, deformation, wear, corrosion, excessive wear, gouges, abrasions and exposed threads)
3. Check for normal function
4. Check for normal return to neutral or "off" position (self-resetting switches return to neutral or "off" position after released)
5. Clean and free of foreign objects
6. Check for correct level, sealing and leaks
7. Labels complete, clear and secure
8. Check for appropriate dimensions/tolerances
9. Fully charged
10. Verify/perform
11. Replace the oil or filter element
12. Correctly lubricated
13. Inspect the carbon brush

DECLARATION OF CONFORMITY

Machinery Directive: 2006/42/EC
Electromagnetic Compatibility Directive:
2014/30/EU

Name of manufacturer or supplier

Hunan Sinoboom Intelligent Equipment Co., Ltd.

Full postal address including country of origin

No.128, East Jinzhou Avenue, Ningxiang High-tech Industrial Park, Changsha, Hunan, China

Authorized Representative

Sinoboom B.V.

Nikkelstraat 26, NL-2984 AM Ridderkerk, The Netherlands

Description of product

Mobile Elevating Working Platform

Name, type or model, batch or serial number

Name: Mobile Elevating Working Platform

Standards used, including number, title, issue date and other relative documents

EN 60204-1:2018/Safety of machinery - Electrical equipment of machines - General requirements

EN 280-1:2022 / Mobile elevating work platforms - Design calculations - Stability criteria - Construction - Safety - Examinations and tests

Declaration

I declare that as the authorised representative, the above information in relation to the manufacture of this product, is in conformity with the stated standards and other related documents following the provisions of the above Directives and their amendments.

Signature of manufacturer

Always for Better Access Solutions



Hunan Sinoboom Intelligent Equipment Co., Ltd.

No.128, East Jinzhou Avenue, Ningxiang High-tech Industrial Park, Changsha, Hunan, China

☎ 0086-0731-87116222 (Sales) & 0086-0731-87116333 (Service)

✉ sales@sinoboom.com

🌐 www.sinoboom.com

North American Subsidiary

Sinoboom North America LLC

105 W Riley Road
Houston, Texas 77047
Tel: (281) 729-5425
E-mail: sales@sinoboom.us

Australia Subsidiary

Sinoboom Intelligent Equipment Pty Ltd.

32-34 Marni Street Danenong South, Vic
3175
E-mail: au@sinoboom.com

Middle East Subsidiary

Sinoboom Middle East FZE

Q4-085 , SAIF-Zone, Sharjah, U.A.E.
E-mail: sales@sinoboom.com

Europe Subsidiary

Sinoboom B.V.

Nikkelstraat 26, NL-2984 AM Ridderkerk,
The Netherlands
Tel: +31 180 225 666
E-mail: info@sinoboom.eu

Singapore Subsidiary

Star Access Solutions Pte. Ltd.

112 Robinson Road #03-01 Robinson 112
Singapore 068902
E-mail: sales@sinoboom.com

Brazil Subsidiary

SINOBOOM Brasil LTDA

Av. Antonieta Piva Barranqueiros, 62 –
Unidade 1 - Distrito Industrial, Jundiaí - SP
Brazil
E-mail: sales@sinoboom.com

Korea Subsidiary

Sinoboom Korea Co., Ltd.

95, Docheong-ro, Yeongtong-gu, Suwon-si,
Gyeonggi-do, Republic of Korea
Tel: 010-8310-8026
E-mail: sales@sinoboom.com

Poland Subsidiary

Sinoboom Poland sp. z o.o.

Ul. Bolesława Krzywoustego 74A
61-144 Poznań, Poland